Panasonic®

Before Starting

Printer Section

Document Management
System Section

Troubleshooting

Appendix

Software
Operating Instructions
(For Document Management System and Printer)

Model No. DP-2310/3010/3510/4510/6010

WORKIO

Before operating this software, please read these instructions completely and keep these operating instructions for future reference.

English

Table of Contents

Before Starting

Printer Section

Document Management System Section

Table of Contents

Document Management System Section

Troubleshooting

Appendix

memo

6

Precautions

For Users in the USA

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Operating Guide, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

Any unauthorized changes or modifications to this equipment would void the users authority to operate this device.

Warning: To assure continued compliance, use only a shielded interface cable when connecting the machine's parallel interface port to the host computer. Also, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

• You need to read the software license agreement before setting up the Printer Driver.

• You need to read the following precautions which are described in the Copier & Facsimile and Internet Fax Operating Instructions manuals.
  1. Installation
  2. Ventilation
  3. Handling
  4. Toner and Paper
  5. For Your Safety

External View and Control Panel

External View

■ **DP-2310/3010**

USB Cable
(USB cable is not included with the product)
● For peak performance and optimal data transmission, purchase an Universal Serial Bus 2.0 (USB2) Hi-Speed Cable. Consult with your service provider for further details.
Note: The USB port is only available if using the printer driver.

LAN Cable (10Base-T/100Base-TX Cable)
(LAN cable is not included with the product)
● Purchase a Category 5 (CAT 5) Cable, compliant with EIA/TIA 568-A-5 standard. Connect to your 10Base-T/100Base-TX Ethernet Network.

■ **DP-3510/4510/6010**

Parallel Interface Cable
(Parallel Interface Cable is not included with the product)
● For peak performance and optimal data transmission, purchase an IEEE 1284 compliant parallel interface cable (maximum length of 20 ft (6m). Consult with your service provider for further details.
Note: The parallel port is only available if using the printer driver.

Parallel Port Connector
● Connect the 36 pin Centronics male end of the cable to the Parallel Port on the machine.

LAN Cable (10Base-T/100Base-TX Cable)
(LAN cable is not included with the product)
● Purchase a Category 5 (CAT 5) Cable, compliant with EIA/TIA 568-A-5 standard. Consult with your service provider for further details. Connection from your 10Base-T/100Base-TX Ethernet Network.

Control Panel

Press Print Key

No.	Name	Function
①	MAIL BOX	Used to print or delete the print data. This feature is available if the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed. (See page 10)
②	JOB CONTROL	Selects printer jobs.
③	OFF LINE	Switches the printer to off-line status. (The printer cannot be set off-line when the DATA indicator is blinking.
④	ON LINE	Switches the printer to on-line status.
⑤	CANCEL PRINT	Used to cancel the print job.
⑥	JOB QUEUE	Selects print job priority, print jobs for deletion and allows viewing of all pending print or copy jobs. (See page 11)
⑦	ON LINE Indicator	Lit : Printer is online Off : Printer is offline
⑧	DATA Indicator	Blink : Data is being received from the PC. On : Printing is being processed. Off : Printer is in standby or printing has been completed.

External View and Control Panel

Control Panel

■ MAIL BOX

Enter User ID and press [OK] key.

Select MAIL BOX or SECURE MAIL BOX

No.	Name	Function
①	Print Jobs	Indicates all current and/or pending print jobs.
②	SELECT ALL	Selects all print jobs. (For MAIL BOX only)
③	PRINT	Prints the job. Machine prompts for the 4-digit password if printing from Security Box.
④	DELETE	Deletes print job(s). Machine prompts for the 4-digit password if deleting from Security Box.
⑤	CLOSE	Closes this screen.

Control Panel

■ **JOB QUEUE**

```
Job Queue

JOB OWNER    FILE NAME     STATUS      TIME  #OFSETS PAGES  JOB TIME
1234567890 123456789012 READY       14:49 999 999 9999min      COPY JOB
                                                                QUEUE
FAX JOB    FAX JOB       READY       09:00 000 000 0001min      PRINT JOB
                                                          01    QUEUE
nakadaira  sfd_mSpec.do READY       09:01 001 001 0001min  06
                                                                CLOSE
MGCS       sfd_mPlan.do READY       09:16 010 010 0010min
```

Enter the 4-digit password
and press OK key.

```
Input Identification Code




         O K          CANCEL
```

```
Print Job Queue
Select Delete or Priority

JOB OWNER    FILE NAME     STATUS      TIME  #OFSETS PAGES  JOB TIME
1234567890 123456789012 READY       14:49 999 999 9999min      SELECT ALL   ②

FAX JOB    FAX JOB       READY       09:00 000 000 0001min      PRIORITY     ③
                                                          01
nakadaira  sfd_mSpec.do READY       09:01 001 001 0001min  05   DELETE       ④

MGCS       sfd_mPlan.do READY       09:16 010 010 0010min      CLOSE        ⑤
```

①

No.	Name	Function
①	Print Jobs	Indicates all current and/or pending print jobs.
②	SELECT ALL	Selects all print jobs.
③	PRIORITY	Set or change the print job(s) priority. This feature is available if the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed.
④	DELETE	Deletes print job(s).
⑤	CLOSE	Closes this screen.

Installing the Printer Driver

Windows 98/Me/NT/2000/XP

1

Insert the Panasonic Document Management System CD-ROM.

2

Click on the desired language.

3

Click the [Next] button.

4

Click **Printer Driver**.

5

Note for Windows 98/Me users:
If your computer does not have the LPR Port Monitor installed, please proceed to "Installing the LPR Monitor" on page 30 before continuing this installation.

Click **Install Printer Driver**.

12

6 Select your machine's model(s) check box and click the Next button.

7 <For DP-2310/3010 only>

Select how your machine will be used, either as a Network Printer or as a USB Printer.

If USB Printer is selected, click the

 Next button and skip to Step 11.

Note: *Make sure that the Power Switch of your machine is OFF and the USB cable is not connected to your computer.*

8 Check **LPT1:** and click the Next button.
(See Note 2 on page 17)

9 Click the Yes button if you would like to change your current default printer to the one that you are installing.

Note: *This dialog box only appears if another printer is already installed.*

Continued on the next page...

Installing the Printer Driver

Windows 98/Me/NT/2000/XP

10

Select your new default printer from the New Printer List and click the | Next | button.

11

The required files are copied.

12a

\<Windows 98/Me>
When this message appears, turn the Power Switch of your machine ON and connect your machine to an available USB Port on your computer.

Windows 98/Me/NT/2000/XP

12b

\<Windows 2000\>

Click the [Yes] button.

When this message appears, turn the Power Switch of your machine ON and connect your machine to an available USB Port on your computer.

Click the [Yes] button.

Printer Section

15

Installing the Printer Driver

Windows 98/Me/NT/2000/XP

12c

<Windows XP>

Click the `Continue Anyway` button.

When this message appears, turn the Power Switch of your machine ON and connect your machine to an available USB Port on your computer.

Select **Install the software automatically** and click the `Next` button.

This message may appear if you have a previous version of the printer driver installed. Select the latest version of the *.inf file and click the `Next` button.

Windows 98/Me/NT/2000/XP

12c

Click the ⬚Continue Anyway⬚ button.

Click the ⬚Finish⬚ button.

13

When the setup process is completed, a message is displayed prompting you to restart your computer.

Click the ⬚Finish⬚ button to restart your computer.

The Panasonic/Panafax Printer Driver have been installed, and the Panasonic/Panafax Printer icon(s) have been added to the Printer folder.

If you are installing the Printer Driver for network printing, please contact your network administrator for the IP Address of the machine and proceed to the next section to install the LPR Monitor service for the version of Windows you are using after your computer has rebooted.

NOTE

1. When installing on Windows NT 4.0 and Windows 2000/XP, logon to the computer/network using an account with administrator rights.
2. If the LPR Monitor is already installed on your PC, select **Create New Port** in step 8. Then, select **Search the network printer** to search the machine(s) connected on your network.

17

Installing the Printer Driver

Connecting with a USB Cable (Windows 98)

When using the USB cable to connect the printer, install the printer driver by following the steps below.
(For DP-2310/3010 only)

1 Connect the printer to the PC with an USB cable.
Turn the Power Switch of your machine ON.

2 The **New Hardware Found** dialog box appears for a brief moment, followed by the **Add New Hardware Wizard** dialog box.

Click the Next button.

3 Select **Search for the best driver for your device**.

Click the Next button.

4 Insert the CD-ROM included in your machine.

18

Connecting with a USB Cable (Windows 98)

5

Select **Specify a location** and type
D:\English\PanaDMS\Driver\Usb\UsbDrv\Win98
(where "D:" is your CD-ROM drive).

6

Click the [Next] button.

7

Click the [Finish] button.

8

The **New Hardware Found** dialog box appears for a brief moment, followed by the **Add New Hardware Wizard** dialog box.

Click the [Next] button.

19

Installing the Printer Driver

Connecting with a USB Cable (Windows 98)

9

Select **Search for the best driver for your device**.

Click the [Next] button.

10

Select **Specify a location** and type **D:\English\PanaDMS\Driver\Usb\Win98** (where "D:" is your CD-ROM drive).

Click the [Next] button.

11

Click the [Next] button.

12

Enter the Printer name and click the [Finish] button.

Connecting with a USB Cable (Windows 98)

13

Click the [Finish] button.

Installing the Printer Driver

Connecting with a USB Cable (Windows Me)

1

Connect the printer to the PC with an USB cable.
Turn the Power Switch of your machine ON.

2

The **New Hardware Found** dialog box appears for a brief moment, followed by the **Add New Hardware Wizard** dialog box.

Select Specify the location of the driver.

Click the [Next] button.

3

Insert the CD-ROM included in your machine.

4

Select **Specify a location** and type **D:\English\PanaDMS\Driver\Usb\UsbDrv\WinMe** (where "D:" is your CD-ROM drive).

Connecting with a USB Cable (Windows Me)

5

Click the Next button.

6

Click the Finish button.

7

The **New Hardware Found** dialog box appears for a brief moment, followed by the **Add New Hardware Wizard** dialog box.
Select Specify the location of the driver.

Click the Next button.

8

Select **Specify a location** and type **D:\English\PanaDMS\Driver\Usb\WinMe** (where "D:" is your CD-ROM drive).

Click the Next button.

Continued on the next page...

Printer Section

23

Connecting with a USB Cable (Windows Me)

9

Click the Next button.

10

Enter the Printer name and click the Finish button.

11

Click the Finish button.

Connecting with a USB Cable (Windows 2000)

1

Connect the printer to the PC with an USB cable.
Turn the Power Switch of your machine ON.

2

The **Found New Hardware** dialog box appears.

Click the [Next] button.

3

Select **Search for a suitable driver for my device**.

Click the [Next] button.

4

Insert the CD-ROM included in your machine.

Continued on the next page...

Connecting with a USB Cable (Windows 2000)

5

Select **Specify a location**.

Click the [Next] button.

6

Type
D:\English\PanaDMS\Driver\Usb\WinXP-2K
(where "D:" is your CD-ROM drive).

Click the [OK] button.

7

Click the [Next] button.

8

Click the [Yes] button.

26

Connecting with a USB Cable (Windows 2000)

9

Click the [Finish] button.

27

Installing the Printer Driver

Connecting with a USB Cable (Windows XP)

1

Connect the printer to the PC with an USB cable.
Turn the Power Switch of your machine ON.

2

The **Found New Hardware Wizard** dialog box appears.
Select **Install from a list or specific location (Advanced)**.

Click the [Next] button.

3

Select **Include this location in the search.**
Type
D:\English\PanaDMS\Driver\Usb\WinXP-2K
(where "D:" is your CD-ROM drive).
Insert the CD-ROM included in your machine.

Click the [Next] button.

Connecting with a USB Cable (Windows XP)

4

Found New Hardware Wizard

Please select the best match for your hardware from the list below.

Panasonic DP-3010

Description	Version	Manufacturer	Location
Panasonic DP-3010	1.0.0.0	Panasonic	c:\windows\inf\oem1.inf
Panasonic DP-3010	1.0.0.0	Panasonic	d:\spanish\panadms\drive
Panasonic DP-3010	1.0.0.0	Panasonic	d:\spanish\panadms\drive
Panasonic DP-3010	1.0.0.0	Panasonic	d:\panadms\driver\usb\wii

⚠ This driver is not digitally signed!
Tell me why driver signing is important

[< Back] [Next >] [Cancel]

This message may appear if you have a previous version of the printer driver installed.

Select the latest version of the *.inf file and click the [Next] button.

5

Hardware Installation

⚠ The software you are installing for this hardware:

Printers

has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)

Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.

[Continue Anyway] [STOP Installation]

Click the [Continue Anyway] button.

6

Found New Hardware Wizard

Completing the Found New Hardware Wizard

The wizard has finished installing the software for:

Panasonic DP-3010

Click Finish to close the wizard.

[< Back] [Finish] [Cancel]

Click the [Finish] button.

Installing the LPR (Line Printer Remote) Monitor

Windows 98/Me

1

Insert the Panasonic Document Management System CD-ROM.

2

Click on the desired language.

3

Click the [Next] button.

4

Click **Printer Driver**.

5

Click **Install LPR Monitor**.

Windows 98/Me

6

The **M-LPR Port Monitor Setup** dialog box appears.

Click the [OK] button.

7

The required files are copied.

8

The setup program copies the necessary files onto the hard disk of your PC.
When the setup process is completed, a message is displayed prompting you to restart your computer.
It is recommended that you restart your computer now so that the LPR Monitor can be started.

Click the [Finish] button.

9

If you have not installed the printer driver yet, please proceed to "Installing the Printer Driver" on page 12.

After your computer has rebooted, click the **Start** button, select **Settings**, and then click **Printers**.

The **Printers** folder appears.

Right-click on the desired printer icon and select **Properties** from the pop-up menu.

Printer Section

31

# Installing the LPR (Line Printer Remote) Monitor

Windows 98/Me

10

The printer properties dialog box appears.

The following step registers the LPR Port for network printing.

Before proceeding, ensure that the printer is installed, connected to the network, turned ON and is operating properly.

11

Select the **Details** tab and click the [Add Port...] button.

12

The **Add Port** dialog box appears. Click the **Other** radio button, select **M-LPR Port Monitor** from "Click the type of port you want to add:" list, and click the [OK] button.

Windows 98/Me

13

The **M-LPR Port Monitor** dialog box appears.

Type the IP Address of the machine in the **Hostname or IP address** window and the queue name (e.g. New105) in the **Queue name:** window.

Click the [OK] button. If an error occurs because the queue name had already been used for the same IP Address, select a different unique name such as "New106".

The screen reverts to the Printer Properties.

14

Check that the "Print to the following port:" has been changed as entered in step 13, and click on the

Apply button first and then the [OK] button.

The printer properties dialog box closes and you have now configured the printer as a network printer.

Printer Section

NOTE   *1. To print data via LAN, the LPR Monitor must be installed on your PC.*

# Installing the LPR (Line Printer Remote) Monitor

Windows NT 4.0

Logon using an account with administrator rights.

1

Click the **Start** button, select **Settings**, and click **Control Panel**.

The **Control Panel** window appears.

Double-click on the **Network** applet.

The **Network** dialog box appears.

2

Click the **Services** tab.

Verify whether the LPR Service is already installed. (Indicated by Microsoft TCP/IP Printing shown in the Network Services list.)

If it is already installed, skip to Step 7. Otherwise continue installing the LPR Service.

3

Click the [Add...] button to display the **Select Network Service** dialog box, and select **Microsoft TCP/IP Printing**.

Click the [OK] button.

34

Windows NT 4.0

4

The **Windows NT Setup** dialog box appears.

Insert the Windows NT 4.0 CD-ROM, and type **D:\i386** (where "D:" is your CD-ROM drive).

Click the | Continue | button.

5

After the files have been copied into the hard drive of your PC, the display returns to the Network dialog box. Confirm that the Microsoft TCP/IP Printing service has been added to Network Services list.

Click the | Close | button.

Note: *If the OK button does not change into a Close button, remove and reinstall the Microsoft TCP/IP Printing service.*

6

When **Network Settings Change** dialog box is displayed, click the | Yes | button to restart your computer now.

You have now completed the LPR Service installation.

7

After your computer has rebooted, log on with an account with Administrator Priviledges, click the **Start** button, select **Settings**, and then click **Printers**.

The **Printers** folder appears.

Right-click on the desired printer icon and select **Properties** from the pop-up menu.

Printer Section

35

Installing the LPR (Line Printer Remote) Monitor

Windows NT 4.0

8

The following step registers the LPR Port for network printing.

Before proceeding, ensure that the printer is installed, connected to the network, turned ON and is operating properly.

Select the **Ports** Tab and click the [Add Port...] button.

9

The **Printer Ports** dialog box appears.

Select **LPR Port** and click the [New Port] button.

10

The **Add LPR compatible printer** dialog box appears.

Enter the IP Address of the printer in the upper field, and "lp" for the print queue name in the lower field.

Click the [OK] button.

(Please wait while the wizard verifies the IP Address and connectivity to the network)

36

Windows NT 4.0

11

The **Printer Ports** dialog box appears.

Click the [Close] button.

12

Select the printer port and click the [OK] button.

The printer properties dialog box closes and you have now configured the printer as a network printer.

Installing the LPR (Line Printer Remote) Monitor

Windows 2000/XP

Logon using an account with administrator rights.

1

Open the **Printers** folder.

Right-click on the desired printer icon and select **Properties** from the pop-up menu.

The printer properties dialog box appears.

2

Select the **Ports** Tab and click the

Add Port... button.

Windows 2000/XP

3

Select **Standard TCP/IP Port** and click the New Port ... button.

4

Click the Next button.

5

Enter the IP Address and the Port Name and click the Next button.

Note: *The Port Name is automatically entered by Windows 2000/XP. You may need to change it as required.*

Printer Section

Installing the LPR (Line Printer Remote) Monitor

Windows 2000/XP

6

Select **Custom** and click the [Settings...] button.

7

1. In the Protocol section, select **LPR**.
2. In the LPR Settings section, enter the **Queue Name** (e.g. LPR1) and select the **LPR Byte Counting Enabled**.
3. Click the [OK] button.

8

Click the [Next] button.

Windows 2000/XP

9

Add Standard TCP/IP Printer Port Wizard

Completing the Add Standard
TCP/IP Printer Port Wizard

You have selected a port with the following characteristics.

SNMP: No
Protocol: LPR, LPR1
Device: 133.185.254.105
Port Name: IP_133.185.254.105
Adapter Type:

To complete this wizard, click Finish.

< Back   Finish   Cancel

Click the [Finish] button.

10

Printer Ports   ? X

Available port types:

Local Port
MGCS USB Port
Standard TCP/IP Port

New Port Type...   New Port...   Close

Click the [Close] button.

11

Panasonic DP-6010 Properties   ? X

General | Sharing | Ports | Advanced | Security | Device

Panasonic DP-6010

Print to the following port(s). Documents will print to the first free
checked port.

Port	Description	Printer
☐ COM1:	Serial Port	
☐ COM2:	Serial Port	
☐ COM3:	Serial Port	
☐ COM4:	Serial Port	
☐ FILE:	Print to File	
☑ IP_133.185.254.1...	Standard TCP/IP Port	

Add Port...   Delete Port   Configure Port...

☑ Enable bidirectional support
☐ Enable printer pooling

Close   Cancel   Apply

Click the [Apply] button.

Click the [OK] button.

The printer properties dialog box closes and
you have now configured the printer as a
network printer.

41

Configuring the Printer Driver Settings

Windows 98/Me

To change the printer settings, open the dialog box for the printer properties by performing the following steps.

1 Click the **Start** button, select **Settings**, and then click **Printers**.

2 Right-click on the desired printer icon in the **Printers** folder, and select **Properties** in the popup menu.

The printer properties dialog box appears.

Windows 98/Me

General Tab

1. **Comment**
   Enter comments to the properties, if any.

   If another user sets up this printer on his or her computer when sharing the printer, the comment specified here will also appear on that computer. However, the comment displayed for an existing user will remain unchanged even if the comment is modified later.

2. **Separator page**
   This feature is not available on your machine.

3. Print Test Page **button**
   Prints a test page. This allows the user to verify if the printer is installed properly.

Printer Section

43

Configuring the Printer Driver Settings

Windows 98/Me

Details Tab

1. **Print to the following port**
   Displays either the port where the printer is connected or the path to the network printer.

   To change the printing destination, either select the printing destination port from the list or enter the network path here.

2. **Print using the following driver**
   Displays the type of the printer driver. Specify the printer being used or a printer model which can be emulated with the printer being used.

3. | Capture Printer Port... | / | End Capture... | **button**
   Assigns a local port to the network connected printer or cancels a local port assigned to the network printer.

4. **Timeout settings - Not selected**
   Specify the amount of time (in seconds) allowed to elapse before the printer comes online. If the printer is not online within this duration, an error message will be displayed.

5. **Timeout settings - Transmission retry**
   Specify the amount of time (in seconds) allowed to elapse before the printer is ready for printing. If the printer is not ready for printing within this duration, an error message will be displayed.

   Increase this value if a timeout error occurs when printing a large document.

6. | Add Port... | / | Delete Port... | **button**
   Adds/deletes a new port or a new network path.

7. | New Driver... | **button**
   Updates or modifies the printer driver.

44

Windows 98/Me

8. `Spool Settings...` **button**

Specify the method of sending (spooling) documents from the program to the printer.

• **Spool Data Format**

Select spool data type (EMF format or RAW format). Specifying RAW format results in a longer time elapsing before an application becomes operational after printing from it.

Note: Spooling by EMF format (enhanced metafile compression) may cause the following problems on some application software.

   1) Printing result is different from the screen display.
   2) Printing requires excessive time.

• **Enable bidirectional support**

This setting enables reception of configuration data and status data from the printer.

9. `Port Settings...` **button**

Modifies printer port settings.

Configuring the Printer Driver Settings

Windows 98/Me

Sharing Tab

1. **Not Shared/Shared As**
   Select whether to display or share this printer with other computers.

2. **Share Name**
   Specify the name of the shared printer. The displayed name can be used as it is or a new name may be entered. The name specified here will be displayed when other users view information about the printer on the network.

3. **Comment**
   You can enter comments regarding a shared printer (such as the type of printer and the location where it is installed). When other users view information about the printer on the network, the comment specified here will be displayed.

4. **Password**
   Specify the password required when other users will connect to this printer.
   Leave the box blank in order not to use any password.

NOTE

*1. **Sharing** Tab in property dialog box is not displayed unless printer sharing has been specified.*

Windows 98/Me

Device Options Tab (For DP-2310/3010 only)

1. **Outer Option**
   Select the installed outer option.

2. **Duplex Unit**
   Select **Installed** if a Duplex Unit is installed.

3. **HDD**
   Select **Installed** if the HDD Unit is installed.

4. Auto Configuration **button**
   When your machine is connected on the network (TCP/IP), click this button to set the Options Configuration automatically.

5. **Number of Paper Trays**
   Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE

1 ***Device Options*** *Tab specifies device-specific settings and settings of optional devices.*

Printer Section

Configuring the Printer Driver Settings

Windows 98/Me

Device Options Tab (For DP-3510/4510/6010 only)

1. **Finisher**
   Select the type of the finisher if one is installed.

2. **Punch Unit**
   Select **Installed** if a Punch Unit is installed.

3. **Large Capacity Paper Tray (LCT)**
   Select **Installed** if a Large Capacity Paper Tray is installed.

4. **HDD**
   Select **Installed** if the HDD Unit is installed.

5. **Number of Paper Trays**
   Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE   *1 **Device Options** Tab specifies device-specific settings and settings of optional devices.*

Windows 98/Me

Paper/Output/Quality/Secure Tab

Refer to All Windows Common Settings (See page 73 - 79).

Printer Section

Configuring the Printer Driver Settings

Windows NT 4.0 (Administrator)

To change the printer settings, open the dialog box for the printer properties by performing the following steps.

1 Logon to the computer/network using an account with administrator rights. (See Note 1)

2 Click the **Start** button, select **Settings**, and then click **Printers**.

3 Right-click on the desired printer icon in the **Printers** folder, and select **Properties** in the popup menu.

The printer properties dialog box appears.

```
Printers                                    _ □ ✕
File  Edit  View  Help

🖨        📁
Add Printer    Pan    Open
              DP-60
                    Pause Printing
                    Set As Default
                    Document Defaults...
                    Sharing...

                    Purge Print Documents

                    Create Shortcut
                    Delete
                    Rename

                    Properties

Displays the properties of the selected items.
```


NOTE

1. *In Windows NT 4.0, setting the properties depends on the log on account. This section describes properties to be specified by the administrator (system manager).*
   See "Configuring the Printer Driver Settings (User)" for details on user properties. (See page 60)

Windows NT 4.0 (Administrator)

General Tab

1. **Comment**
   Enter comments to the properties, if any.

   If another user sets up this printer on his or her computer when sharing the printer, the comment specified here will also appear on that computer. However, the comment displayed for an existing user will remain unchanged even if the comment is modified later.

2. **Location**
   Specifies the printer location.

3. **Driver**
   Displays the printer driver type. Specify the printer being used or a printer model that can be emulated with the printer being used.

4. New Driver... **button**
   Updates or modifies the printer driver.

5. Separator Page... **button**
   This feature is not available on your machine.

6. Print Processor... **button**
   Specify the processor to be used for printing (Print Processor) and the data type (Default Data type).

   The processor and data type affect the manner in which the printer functions in Windows NT. Normally they do not need to be modified. However, modification might be necessary when the printer is used with a special application.

7. Print Test Page **button**
   Prints a test page. This allows the user to verify if the printer is installed properly.

Configuring the Printer Driver Settings

Windows NT 4.0 (Administrator)

Ports Tab

1. **Print to the following port(s)**
   Displays a list of available ports for printing (Port), their status (Description) and printers that are connected to these ports (Printer).

2. [Add Port...] / [Delete Port] **button**
   Adds/deletes a new port or a new network path.

3. [Configure Port...] **button**
   Configures the selected port. In case of a parallel port, Transmission Retry should be specified. (See Note 1, 2)

4. **Enable bidirectional support**
   This setting enables reception of configuration data and status data from the printer.

5. **Enable printer pooling**
   Printer pooling allows data sent to one logical printer to be received and printed by two or more printers. With printer pooling enabled, a transmitted printing job is output to the first printer that is ready for printing.

NOTE
1. *Specify time (seconds) waiting for the printer to be ready for printing. If a printer is not ready for printing after the specified time has elapsed, an error message is displayed.*
2. *If a timeout error occurs frequently upon printing a large size document, specify a larger value here.*

Windows NT 4.0 (Administrator)

Scheduling Tab

1. **Available**
   Schedules when the printer is available for operation. Specify operating hours when **From-To** is selected.

2. **Priority**
   Sets printing priority. The slider allows the priority to be adjusted from 1 through 99.

3. **Spool print documents... / Print directly to the printer**
   Specify how documents should be sent from an application to the printer.

4. **Hold mismatched documents**
   The spooler compares document settings against printer settings and holds printing of a document if its settings (Paper Size, Orientation, etc.) do not match the printer settings.

5. **Print spooled documents first**
   Always prints spooled documents first regardless of printing priority.

6. **Keep documents after they have printed**
   Holds documents in the print queue even after they have been printed. These documents can be printed again directly from the queue regardless of the state the application is in.

Configuring the Printer Driver Settings

Windows NT 4.0 (Administrator)

Sharing Tab

1. **Not Shared/Shared**
   Select whether to display or share this printer with other computers.

2. **Share Name**
   Specify the name of the shared printer. The displayed name can be used as it is or a new name may be entered. The name specified here will be displayed when other users view information about the printer on the network.

3. **Alternate Drivers** (See Note 1)
   Allows other operating systems' printer drivers to be loaded. When users of these operating systems connect to the printer, the printer driver is automatically loaded.

NOTE

1. *When sharing a printer on the network, the print driver needs to be installed on the print server only, other computers will automatically copy and use that driver.*
   For this reason, the print server must be ready with printer drivers for all the operating systems of all the computers that will be sharing the printer.

Windows NT 4.0 (Administrator)

Security Tab

1. | Permissions | **button**
   Set printer access privileges.

2. | Auditing | **button**
   Displays the users who have used this printer and how they used it.

3. | Ownership | **button**
   Set the ownership of the printer.

NOTE

1. In order to utilize these features, first you need to select Autid... from User Manager's Policies and enable File and Object Access in the Audit Policy dialog box.

55

Configuring the Printer Driver Settings

Windows NT 4.0 (Administrator)

Device Options Tab (For DP-2310/3010 only)

1. **Outer Option**
   Select the installed outer option.

2. **Duplex Unit**
   Select **Installed** if a Duplex Unit is installed.

3. **HDD**
   Select **Installed** if the HDD Unit is installed.

4. **Halftone Setup**

   | Halftone Setup... | **button**

   Select the halftoning method to be used (halftones specific to the printer).
   Select it according to the details of the data and your preference.

Windows NT 4.0 (Administrator)

- **Halftone Pattern**
  Select the pixel size to be used for halftones.
  The greater the value, the coarser the image would become. However, a larger value is suited for printing large areas.
  The Enhanced pattern allows printing at a higher resolution using the same number of pixels. However, the pattern might generate unnatural lines, patterns, moire effects, and so on depending on the image to be printed.

- **Device Gamma**
  Adjust the gamma of print images (color intensities).

- **Pixel Diameter**
  Adjust the darkness of the print image. Move the slider to specify the pixel size. You can choose between specifying the real size in inches or specifying it as a percentage relative to the printer resolution.

- **Luminance (CIE Y)**
  Adjust the luminosity of the print image.

5. Auto Configuration **button**
   When your machine is connected on the network (TCP/IP), click this button to set the Options Configuration automatically.

6. **Number of Paper Trays**
   Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE   *1* ***Device Options*** *Tab specifies device-specific settings and settings of optional devices.*

Configuring the Printer Driver Settings

Windows NT 4.0 (Administrator)

Device Options Tab (For DP-3510/4510/6010 only)

1. **Finisher**
   Select the type of the finisher if one is installed.

2. **Punch Unit**
   Select **Installed** if a Punch Unit is installed.

3. **Large Capacity Paper Tray (LCT)**
   Select **Installed** if a Large Capacity Paper Tray is installed.

4. **HDD**
   Select **Installed** if the HDD Unit is installed.

5. **Halftone Setup**

   | Halftone Setup... | **button**

   Select the halftoning method to be used (halftones specific to the printer).
   Select it according to the details of the data and your preference.

Windows NT 4.0 (Administrator)

• **Halftone Pattern**
Select the pixel size to be used for halftones.
The greater the value, the coarser the image would become. However, a larger value is suited for printing large areas.
The Enhanced pattern allows printing at a higher resolution using the same number of pixels. However, the pattern might generate unnatural lines, patterns, moire effects, and so on depending on the image to be printed.

• **Device Gamma**
Adjust the gamma of print images (color intensities).

• **Pixel Diameter**
Adjust the darkness of the print image. Move the slider to specify the pixel size. You can choose between specifying the real size in inches or specifying it as a percentage relative to the printer resolution.

• **Luminance (CIE Y)**
Adjust the luminosity of the print image.

6. **Number of Paper Trays**
Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE   *1* ***Device Options*** *Tab specifies device-specific settings and settings of optional devices.*

Configuring the Printer Driver Settings

Windows NT 4.0 (User)

To change the printer settings, open the dialog box for the printer properties by performing the following steps.

1   Select **Print** in the **File** menu of the application.

2   Select the printer model in the name list box.

3   Click the [Properties...] button in the **Print** dialog box.

4   The printer properties dialog box appears. Click the desired tabs of the dialog box and specify the properties.
(See Note 1)
(See page 73 - 79)

(NOTE)   *1. In Windows NT 4.0, setting properties depends on the logon account. This section describes properties to be specified by a user, upon executing a print operation in an application. See "Configuring the Printer Driver Settings (Administrator)" for details on administrator properties. (See page 50)*

Windows 2000/XP (Administrator)

To change the printer settings, open the dialog box for the printer properties by performing the following steps.

1   Logon to the computer/network using an account with administrator rights.

2   Click the **Start** button, select **Settings**, and then click **Printers**.

3   Right-click on the desired printer icon in the **Printers** folder, and select **Properties** in the popup menu.

The printer properties dialog box appears. (See Note 1)

Printer Section

NOTE

1. *In Windows 2000/XP, setting the properties depends on the logon account. This section describes properties to be specified by the administrator (system manager). See "Configuring the Printer Driver Settings" for details on user properties. (See page 72)*

Configuring the Printer Driver Settings

Windows 2000/XP (Administrator)

General Tab

1. **Printer Name**
   Name of the printer specified upon installation is displayed.

2. **Location and Comment**
   Enter a comment about the location of the printer and information about the printer.

   If a printer is shared, the location and comments specified in this field appear when another user sets up this printer on his/her computer. After completion of setup, however, changing this comment does not update the location and comment appearing on users PCs.

3. **Model**
   Model name of the printer is displayed.

4. **Features**
   Functions and settings of the printer are displayed.

5.   Printing Preferences...   **button**
   Changes properties (print settings) specifiable for each user.
   Refer to "Configuring the Printer Driver Settings (User)" for details on settings (See page 72).

6.   Print Test Page   **button**
   Prints a test page. This allows the user to verify if the printer is installed properly.

Windows 2000/XP (Administrator)

Sharing Tab

<Windows 2000>

<Windows XP>

1. **Not Shared/Shared As (Do not share this printer/Share this printer)**
   Specify if this printer is displayed or shared with other computers.

   For sharing a printer, specify the share name of a printer. A name specified here appears when other users view the printer information on a network.

2. Additional Drivers... **button**
   Install additional printer drivers on the system. (See Note 1)

   When users running different versions of Windows share a printer, installing additional drivers avoids the need for installing new drivers on their systems.

NOTE

1. *When sharing a printer on the network, the print driver needs to be installed on the print server only, other computers will automatically copy and use that driver.*
   For this reason, the print server must be ready with printer drivers for all the operating systems of all the computers that will be sharing the printer.

Printer Section

Configuring the Printer Driver Settings

Windows 2000/XP (Administrator)

Ports Tab

1. **Print to the following port(s)**
   Displays a list of ports that allow printing, their status (description), and printers connected to the ports.

2. [Add Port...] / [Delete Port] **button**
   Adds/deletes a new port or a new network path.

3. [Configure Port...] **button**
   Configure the port that is selected. On a parallel port, wait time (in seconds) for retransmission is specified. (See Note 1, 2)

4. **Enable bidirectional support**
   This setting enables reception of configuration data and status data from the printer.

5. **Enable printer pooling**
   Printer pooling allows data sent to one logical printer to be received and printed by two or more printers. With printer pooling enabled, a transmitted printing job is output to the first printer that is ready for printing.

NOTE
1. *Specify the time (seconds) waiting for the printer to be ready for printing. If the printer is not ready for printing after the specified time has elapsed, an error message is displayed.*
2. *If a timeout error occurs frequently upon printing a large size document, specify a larger value here.*

Windows 2000/XP (Administrator)

Advanced Tab

1. **Always available/Available from**
   Specify the operating schedule for a printer. Selecting **Available from** allows specifying an available operation time.

2. **Priority**
   Specify the priority in printing. Priority is adjustable from 1 to 99. Documents of higher priority are printed before those of lower priority.

3. **Driver**
   Displays the printer driver type. Specify the printer being used, or a printer model that can be emulated with the printer being used.

4. **New Driver...** **button**
   Updates or modifies the printer driver.

5. **Spool print documents so program finishes printing faster**
   Specify the method of sending a document from the program to the printer.

6. **Hold mismatched documents**
   The spooler compares document settings against printer settings and holds printing of a document if its settings (Paper Size, Orientation, etc.) do not match the printer settings.

7. **Print spooled documents first**
   Always prints spooled documents first regardless of printing priority.

8. **Keep printed documents**
   After printing, documents are kept in the queue. The documents are allowed to be reprinted directly from the queue regardless of the status of an application.

Configuring the Printer Driver Settings

9. **Enable advanced printing features**

   Enables advanced printing features. Optional features of the printer (page ordering, booklet printing, numbering on sheets) are enabled. These features can be disabled if a problem occurs due to incompatibility. Disabling the features may also disable the printing options.

10. Printing Defaults... **button**

    Specifies standard (default) values for the properties (print settings) specifiable for each user. If a local printer is shared, the settings here are used as printing defaults for other users.

    Refer to "Configuring the Printer Driver Settings (User)" for detailed settings. (See page 72)

11. Print Processor... **button**

    Specify a print processor and data type to be used for printing.

   The processor and data type define operations of printers under Windows 2000/XP.

    Usually no change is required in the settings. Use of a printer from some applications, however, may require changes in the settings.

12. Separator Page... **button**

    This feature is not available on your machine.

66

Windows 2000/XP (Administrator)

Security Tab

Displays a list of users and groups to whom printer access is assigned to. A list of standard permissions for each group or user is displayed. Check or uncheck the checkboxes for permitting or prohibiting access. Gray checkbox indicates the permission inheritance.

1. [Add...] / [Remove] **button**
   Add or delete a user or group from the list.

2. [Advanced...] **button**
   Specify access to a printer, audit, and owner. (See Note 1, 2)

NOTE
1. *Windows 2000 provides the capability of managing access to various objects (e.g. printers) by users.*
2. *Refer the Windows 2000 documentation for details on access permission, audit, and owner.*
3. *The Security Tab is not shown in Windows XP.*

Configuring the Printer Driver Settings

Windows 2000/XP (Administrator)

Device Options Tab (For DP-2310/3010 only)

1. **Outer Option**
   Select the installed outer option.

2. **Duplex Unit**
   Select **Installed** if a Duplex Unit is installed.

3. **HDD**
   Select **Installed** if the HDD Unit is installed.

4. **Halftone Setup**

   | Halftone Setup... | **button**

   Select the halftoning method to be used (halftones specific to the printer).
   Select it according to the details of the data and your preference.

Windows 2000/XP (Administrator)

- **Halftone Pattern**
  Select the pixel size to be used for halftones.
  The greater the value, the coarser the image would become. However, a larger value is suited for printing large areas.
  The Enhanced pattern allows printing at a higher resolution using the same number of pixels. However, the pattern might generate unnatural lines, patterns, moire effects, and so on depending on the image to be printed.

- **Device Gamma**
  Adjust the gamma of print images (color intensities).

- **Pixel Diameter**
  Adjust the darkness of the print image. Move the slider to specify the pixel size. You can choose between specifying the real size in inches or specifying it as a percentage relative to the printer resolution.

- **Luminance (CIE Y)**
  Adjust the luminosity of the print image.

5. Auto Configuration **button**
   When your machine is connected on the network (TCP/IP), click this button to set the Options Configuration automatically.

6. **Number of Paper Trays**
   Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE   *1 **Device Options** Tab specifies device-specific settings and settings of optional devices.*

Configuring the Printer Driver Settings

Windows 2000/XP (Administrator)

Device Options Tab (For DP-3510/4510/6010 only)

1. **Finisher**
   Select the type of the finisher if one is installed.

2. **Punch Unit**
   Select **Installed** if a Punch Unit is installed.

3. **Large Capacity Paper Tray (LCT)**
   Select **Installed** if a Large Capacity Paper Tray is installed.

4. **HDD**
   Select **Installed** if the HDD Unit is installed.

5. **Halftone Setup**

   | Halftone Setup... | **button**

   Select the halftoning method to be used (halftones specific to the printer).
   Select it according to the details of the data and your preference.

Windows 2000/XP (Administrator)

- **Halftone Pattern**

Select the pixel size to be used for halftones.

The greater the value, the coarser the image would become. However, a larger value is suited for printing large areas.

The Enhanced pattern allows printing at a higher resolution using the same number of pixels. However, the pattern might generate unnatural lines, patterns, moire effects, and so on depending on the image to be printed.

- **Device Gamma**

Adjust the gamma of print images (color intensities).

- **Pixel Diameter**

Adjust the darkness of the print image. Move the slider to specify the pixel size. You can choose between specifying the real size in inches or specifying it as a percentage relative to the printer resolution.

- **Luminance (CIE Y)**

Adjust the luminosity of the print image.

6. **Number of Paper Trays**

Select the number of available paper trays for the printer if an optional Paper Feed Module is installed.

NOTE

1 ***Device Options*** *Tab specifies device-specific settings and settings of optional devices.*

Configuring the Printer Driver Settings

Windows 2000/XP (User)

Changes the printer settings. Display the printer settings dialog box by performing the steps below.

1 Select **Print** in the **File** menu of the application.

2 Select the printer model in the name list box.

3 Click the [Properties...] button in the **Print** dialog box.

4 The printer properties dialog box appears. Click the desired tabs of the dialog box and specify the properties.
(See Note 1)
(See page 73 - 79)

NOTE

1. *In Windows 2000/XP, setting the properties depends on the log on accounts. This section describes properties to be specified by a user, upon executing a print operation in an application. See "Configuring the Printer Driver Settings (Administrator)" for details on administrator (system manager) properties. (See page 61)*

All Windows Common Settings

Paper Tab

1. **Paper Size**
   Select a document size.

2. **Copies (DP-2310/3010: 1-999, DP-3510/4510/6010: 1-250)**
   Specify the number of copies to be printed. If the number of copies to be printed can be specified within the application, indicate one copy here and specify the number of copies in the Print dialog box of the application.

3. **Orientation**
   Specifies how the document is positioned on the page. Portrait orients the print vertically. Landscape orients the print horizontally. If available, Rotated Landscape rotates the paper 90 degrees counterclockwise.

4. **Output Size**
   Specifies the paper size to use. The various paper sizes listed match those supported by your printer.

5. **Zoom (50-200)**
   Specify an enlargement or reduction percentage when printing documents. If enlargement/reduction can be set within the application, indicate 100% here and specify the enlargement/reduction percentage in the Print dialog box of the application.

6. **Paper Source**
   Specify where the paper you want to use is located in the device. If you choose **Auto Tray Selection**, the printer driver will automatically select an appropriate tray according to the Paper Size selected.

7. **Print Properties Status Icons**
   Show the print status for the following properties.
   • Paper Style (Output Tab)
   • N in 1 (Output Tab)
   • Sort (Output Tab)

8. **Status Monitor**
   Recalls Network Status Monitor. (See page 168)

All Windows Common Settings

Output Tab

\<For DP-3510/4510/6010\>

\<For DP-2310/3010\>

1. **Paper Style**
   Select duplex printing for printing on both sides of the paper.
   You can select the printing style among 1-Side/2-Sided (Long Edge) /2-Sided (Long Edge Margin) /2-Sided (Short Edge) /2-Sided (Short Edge Margin).

   • **Binding Direction**
   Select the binding side (Long Edge/Short Edge) for duplex printing.

   • **Binding Margin**
   Select the binding margin upon duplex printing. The width of the binding margin is specified on the device.

2. **N in 1**
   Specify the layout pattern for printing multiple documents on a single sheet of paper.

All Windows Common Settings

3. **Sort**

   Select whether to Stack or Sort when printing multiple copies.
   Note: Sort settings made on the printer driver screen have priority.
   It is not recommended to make them on the application screen.

   Non Sort

   Sort

   Rotate Stack

   Rotate Sort

   Shift Stack

   Shift Sort

4. **Staple**

   Select the staple position. Available if the optional Finisher (DA-FS300, FS330, FS355, FS600 or FS605) is installed. Available for up to 30 sheets (Letter/A4).

   For DA-FS330, 355, 600 or 605

   Portrait (Left 1/Left 2/Right 1/Right 2 Position)

   Landscape (Left 1/Right 1/Top Position)

   For DA-FS300

   Portrait (Left 1/Right 1 Position)

   Landscape (Left 1/Right 1 Position)

All Windows Common Settings

5. **Punch** (For DP-3510/4510/6010 only)
   Select the punch position. Available if the optional Punch Unit (DA-SP31) is installed.

You can choose Left/Right/Top regardless of paper orientation.

6. **Finisher Bin/Output Tray**
   You can select the type of the output bin or tray.
   Possible when the optional finisher is installed.
   Note: <DP-2310 / 3010 only>
   Before selecting the Inner Upper Exit Tray, please ensure that the Exit Tray (Inner) (DA-XN200) is installed.

All Windows Common Settings

7. Advanced... **Button**

• **Print All Text as Black (Windows 98/Me only).**
All colored text is printed as solid black

• **Print Blank Pages**
Select whether the blank pages are printed.

• **Duplex Notice (For DP-2310/3010 only)**
Check whether **"2-Sided Print"** is printed on the footer of 1st page when printing with 2-Sided Page Style.

• **Copies**
When printing a large amount of data with sort mode, the machine might not be able to print due to lack of memory capacity.

In this case, select **Print Controlled**, as sorting is processed by the printer driver. However, this mode may take more time to print.

Configuring the Printer Driver Settings

All Windows Common Settings

Quality Tab

<Windows 98/Me>   <Windows NT/2000/XP>

1. **Halftone** (For Windows 98/Me only)
   Select either None or Dither.

2. **Resolution**
   Select the print resolution (300 dpi / 600 dpi). (See Note1)

3. **Contrast**
   Adjust the contrast of print images. (**Note:** Only if Halftone is set to None.)

4. [Halftone Color Adjustment...] button (For Windows NT/2000/XP only)

- **Contrast**
  Adjust the contrast of print images.
- **Brightness**
  Adjust the brightness of print images.
- **Dark Picture**
  Select this option in order to print dark images brighter.
- **Negative**
  Select this option in order to print images with black and white reversed.
- **Input RGB Gamma**
  Adjust the gamma of print images (color intensities). Red, Green and Blue can also be adjusted individually.
- **Black Ref/White Ref**
  Adjust the difference between the darkest and lightest colors of an image. Increasing the Black Ref value or decreasing the White Ref value will intensify the contrast of the image but reduces the range of colors in between.
- **Picture**
  Select a test pattern type.
  Selecting the View check box will display halftone adjustment results in the test pattern.

NOTE

1. *dpi (dots per inch) represents the number of dots contained in one inch. The larger the value, the higher the resolution would be.*

78

All Windows Common Settings

Secure Tab

1. **Mailbox (Available if the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed.)**
   Check this checkbox and enter the User ID (up to 8 digits) when storing the print data into the mailbox of the machine.

2. **Secure Mailbox (Available if the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed.)**
   Check this checkbox , enter the User ID (up to 8 digits) and the password (4 digits) when storing the print data into the secure mailbox of the machine.

3. **Dept counter mode On**
   Check this box and enter the department code if your administrator requires departmental codes in order to print.

Print Operation

Printing from Windows Applications

If the printer driver is installed properly and a printer is selected as the default printer (See Note 1) in the printer setup, printing can be accomplished from any Windows application with simple operations.

To print from most Windows applications, use the **Print...** command in the **File** menu. Selecting the **Print...** command typically displays the following Print dialog box:

After selecting the print range to be printed and the number of copies, click on [OK] to start printing.

While documents are being printed, a printer icon appears in the System Tray near the clock on the bottom right hand corner of the screen. The icon disappears when printing is completed.

You may double-click on the printer indicator in the system tray to open and verify the details of the print queue in the spooler.

NOTE
1. *Follow the steps below to set a default printer:*
   1) *Click the Start button and select **Printers** in the **Settings** menu.*
   2) *Select the printer icon in the window and select **[Set as Default]** in popup menu by right-clicking it. Then the check mark is displayed.*

Printing on Network

When sharing a printer by connecting two computers via a crossover cable or using a hub, a connection among computers must be established. (See Note 1, 2)

Establishing a connection among computers can be verified by displaying the connected computers in Network Neighborhood on the desktop.

The settings for printer sharing are specified by performing the following steps.

Printer server (PC connected to a printer)

1 Install the printer driver on the computer to be connected to the machine.

2 Click the **Start** button, select **Settings**, and then click **Printers**.

3 Right-click on the desired printer icon and select **[Sharing...]** in the popup menu.

4 Select **Shared As** in the properties dialog box.

5 Click the [OK] button.

Upon completing this setting, the shape of the icon changes indicating that the printer is shared.

NOTE

1. *Refer to the manual for the network card and Windows user's guide for connections among computers.*
2. *On Windows 98/Me, a computer connected to a printer must be set up to allow printer sharing by performing the following operations:*
   1) *Double-click on **Network** in control panel, and then click [File and Print Sharing...] button in the **Configuration** tab.*
   2) *Check **[I want to be able to allow others to print to my printer(s).]** in the File and Print Sharing dialog box.*

Printing on Network

Remote (PC that uses another computer's printer)

1 Click the **Start** button, select **Settings**, and then click **Printers**.

2 Double-click **Add Printer** in the printers folder window.
The Add Printer Wizard appears.

3 Select **Network Printer**.
Click the [Next] button.

4 Specify the other computer's printer by entering the network path.

Then, complete the installation following the instructions of the Add Printer Wizard.

The operations above enables output from the remote computer to a printer connected to the printer server.

memo

Installing the Document Management System

Windows 98/Me/NT/2000/XP

1

Insert the Panasonic Document Management System CD-ROM. (See Note 1 and 2 on page 87)

2

Select the language.

3

Click the [Next] button.

4

Click **Panasonic-DMS**.

5

Click **Install Panasonic-DMS Software**.

Installing the Document Management System

Windows 98/Me/NT/2000/XP

6

Click the **Typical button**.

> **Note:** *The Panafax Desktop isn't installed depending on the model in the Typical Installation. If you wish to install the Panafax Desktop, select the Custom Installation and check the box of the Panafax Desktop.*

7

Verify the installation destination and click the
Next button.

8

Verify the data folder destination and click the
Next button.

> **Note:** *When installing Panafax Desktop, after click Next button Select Panafax Desktop Type screen is indicated. Please select your model connection type and click Next button. Please refer to the Installation and Setup section of Panafax Desktop.*

9

Select **General User** and click the Next button.

> **Note:** *If selecting **Administrator**, the network configuration editor and network address book editor will also be installed on your PC.*

85

Windows 98/Me/NT/2000/XP

10

Select **It is started with Windows** and click the

[Next] button if you want to register the Panasonic Communications Utility to start with Windows.

11

Select **Set the Document Viewer** and click the

[Next] button if you want to set the Document Viewer as the default application to view TIFF files.

12

Enter the program folder name and click the

[Next] button.

Note: *When installing Panafax Desktop on Windows 98/NT, after click* [Next] *button the Microsoft Data Access Components message is displayed. Click* [OK] *to continue the installation.*

13

The required files are copied.

Installing the Document Management System

14

When the setup process is completed, a message is displayed prompting you to restart your computer.

Click the [Finish] button to restart your computer.

When installing Panafax Desktop on Windows 98/NT, after rebooting your PC, the Microsoft Data Access Components are automatically installed. Install it in accordance with the directions of the screen.
The Panasonic Document Management System folder has been added to the Program menu, and the installation has now completed.

NOTE

1. *Before updating the software, be sure to remove the older version of the software, using the "Uninstall" shortcut in the Control Panel.*
2. *When installing on Windows NT 4.0/2000/XP, logon to the computer using an account with administrator rights.*

Document Manager

Main Window

Document Manager is an application for managing documents (image files). By utilizing the Document Manager and Document Viewer (See page 106) in combination, a number of documents (image files) can be classified, managed, browsed, and edited.

Selecting **Panasonic** → **Panasonic Document Management System** → **Document Manager** from **Programs** on the **Start** menu displays the main window of the Document Manager.

1. **Title Bar**
   Displays the title of the screen.

2. **Menu Bar**
   Displays the menus of the Document Manager.

3. **Tool Bar**
   Displays tool buttons of the Document Manager. Tool buttons correspond to functions of the menus in the menu bar.

4. **Folder Window**
   Displays the folders containing the documents in tree form.

5. **Link Icon**
   Dropping a dragged document onto a link icon will activate the application corresponding to the function of the icon.

6. **Status Bar**
   Displays information such as the number of documents in a folder, the number of selected documents, file sizes, etc.

Main Window

7. **Document Window**
   Displays a list of documents in the selected folder.

   Documents are displayed in thumbnails (reduced images). Page number and ◀ and ▶ buttons are displayed at the bottom of a thumbnail image for grouped documents (configured with two or more pages).

   • Image data files
     A thumbnail image of the document is displayed.

   • Application data files
     A thumbnail image of the document with its original application icon is displayed (i.e. Word, Excel and PowerPoint).

   Clicking on the ◀ and ▶ buttons turns the page to a multi-page document.

Document Management System Section

89

Document Manager

Basic Operations

The Document Manager allows editing and managing documents displayed in thumbnail images by dragging and dropping. The function enables various operations as described below:

- **Selecting Documents**
  Clicking thumbnail images in the document window allows selection of documents. Dragging a mouse pointer on the screen or clicking with the Shift key held down allows selecting two or more documents at one time.

- **Editing Documents**
  Double-clicking thumbnail images in the document window activates the Document Viewer (See Note 1) (See page 106), allowing opening and editing of documents.

- **Creating Documents**
  Drag-and-drop any application file into the Document Manager to create a new document. A thumbnail image file is created and the application icon is displayed.

Basic Operations

- **Copying/Moving Documents**
  Dragging a thumbnail image from the document window and dropping it onto a folder in the folder window moves the document to the folder. Drag-and-drop with the Ctrl key held down to copy a document.

Dragging a document and dropping it onto another document in a document folder results in grouping the two documents together.

Dragging a document and dropping it on a link icon activates an application corresponding to the function of each icon.
Link icons are registered and deleted by selecting **Launch To Another Application** →**External Application Setup** from the **File** menu.

- Dragging a document and dropping it onto "**Shared Folder**" allows other computers connected to the same network to access it.
  Browse "Shared Folder" for how to create shared folders.

Setting Plug-in

• **Import document (from file)**
Selecting **Open** from the **File** menu displays a dialog box for selecting files. The dialog box allows importing image files saved in a computer as documents into the folder.

An attempt to import files that cannot be handled by Document Manager results in displaying an error shown below. Press **OK** and verify the file format.

Dragging and dropping a selected document onto a link icon at the bottom of the window activates an application specified for the link icon, and opens the image file.

The link icons can be Added/Removed by selecting **Launch To Another Application** →**External Application Setup** in the **File** menu.

The following applications can be specified as destinations of the Document Manager:

- Draw/Graphics software (applications such as MS-Paint, Photoshop etc.)
- OCR software (application such as e-Typist, etc.)
- PC-FAX software
- E-Mail software (MAPI-compatible mail application such as MS-Outlook, Netscape Messenger etc.)
- Others
  (Other application documents such as MS-Word, MS-Excel, etc.)

NOTE

1. Document Viewer provides a function to add various graphics and text to an image.
The graphics and text added to an image are called "Annotation." See "Annotation Menu" (See page 119) for details on annotation.

File Menu

- **New Folder**
  Create a new folder under the folder that is currently selected. Path of a folder to be created can be specified as required.

- **Shared Folder**
  Create a new shared folder. Documents in the shared folder can be shared through the network from different computers.

- **Released Shared Folder**
 Release the shared folder. Documents in the shared folder will be released from a network.

- **Open**
  A file saved in the computer can be imported into the folder as a document.

- **Save As**
  A document is saved as an ordinary image file under a specified name.

- **Rename**
  Change the name of a document.

Document Manager

File Menu

• **Properties**
  Displays the file properties.

• **Backup**
  Creates a back up of the documents stored in the selected folder.

File Menu

• **Print**
  Prints the document selected in the document window.

• **Print Setup** (See Note 1)
  Specify layout and printing size for a document to be printed.

  1. **Horizontal Position and Vertical Position**
     Adjust the printing position on the sheet.

  2. **Print Size**
     Select printing in original size or printing in accordance with the sheet size.

  3. **N in 1**
     Select for printing reduced pages on one sheet.

NOTE

1. **Print Setup** *specifies printing or not printing annotations edited in the Document Viewer. See "Annotation Menu" (See page 119) for details on annotation.*

Document Manager

File Menu

• **Launch To Another Application**
Opens the document selected in the document window with a specified application.

Selecting **External Application Setup** displays a dialog box for adding/changing/deleting applications. (See Note 1)

Clicking the **Add** button displays the Add External Application dialog box.

1. **Name**
If an external application is specified, the name in this field appears on the link icon.

2. **Application Type**
Specify the application type.

3. **Program File**
Specify the execution file and the path of the application.

4. **MAPI Compliant**
Check here if the e-mail application is compatible with MAPI.

5. **Printer**
Specify the printer driver if seledting PC-FAX/Printer on the Application Type.

NOTE   *1. See "Setting Plug-in" (page 92) to specify an external application.*

File Menu

• **Trash Can**
  - **Open Trash Can**
    Opens the Trash Can and displays files in it. Selecting documents and clicking the [Undo] button restores documents that have been discarded.

    Click the [Delete] button to delete the selected document.

  - **Empty Trash Can**
    Deletes the files in the Trash Can. If the documents are emptied from the Trash Can, they are permanently deleted. They are **Not** stored in the Recycle Bin.

Document Manager

Edit Menu

• **Undo**
Undoes the last editing operation done.

• **Cut**
Deletes a selected document from a folder and copy it to the
clipboard.

• **Copy**
Copies a selected document to the clipboard.

• **Paste**
Pastes a document from the clipboard into the selected folder.

• **Delete**
Deletes a selected document from a folder to the Trash Can.
A confirmation message for deletion appears.

• **Select All**
Selects all documents in the folder.

• **Find**
Searches for documents by specifying a document name,
creation date, character string or DD Code in the document.

Note: The DD Code Tab is available when the Options Menu
is set to enable the DD Function (See page 102).

View Menu

- **Tool Bar**
  Switches between displaying/hiding the tool bar.

- **Status Bar**
  Switches between displaying/hiding the status bar.

- **List Format/Thumbnail Format**
  Switches between list display and thumbnail display in the document window.

- **Show Annotation**
  Switches between displaying and hiding annotation.

- **Arrange Folders**
  Sorts the document folders by name or date.

- **Arrange Document**
  Sorts the documents in the current folder in the specified order (Name, Type, Size or Date).

- **Lines up Documents**
  Line up the documents in the document window.

- **Refresh**
  Refreshes the contents of the Document Manager.

Document Manager

Document Menu

• **Open**
Opens a selected document, activates the Document Viewer (See page 106), and opens the document for editing.

• **Duplicate**
Makes a copy of the selected document in the folder.

• **Rotate**
Rotates the selected document.
- Rotate Left
- Rotate 180 Degrees
- Rotate Right

• **Group**
Makes a group of two or more selected documents. The grouped documents are indicated by page number and ◀ and ▶ buttons at the bottom of a thumbnail image.

- **Every Document**
  The selected documents are grouped.

- **Every Page Alternately**
  Groups pages alternately.

- **Every Page Reverse Alternately**
  Groups pages alternately by reversing the pages.

Document Menu

• **Ungroup**
Cancels the grouping for grouped documents. Either dividing all pages into individual documents or releasing only specified documents from a group can be selected.

• **Enhancement**
Applies the following correction to a selected document:

- **Correct Skew**
Detects any inclination of the document and automatically correct it.

- **Enhance Edge**
Enhances edges (borders) of images.

- **Eliminate Noise**
Removes noise on the document.

- **Reverse Gradation**
Displays images in reverse.

• **Page**
Selects pages to be displayed in thumbnail among grouped documents.

Selecting **Rearrange Page** displays the Rearrange Pages dialog box. The order of the pages are changed by selecting, dragging and dropping the pages.
Click the **Reverse Order** button to reverse the page order.

• **Attached File**
Opens a dialog box to launch the application associated with the selected attachment.

• **File Conversion**
Creates an image of the selected attachment.

# Document Manager

Options Menu

- **Setup**
  Selects the expansion feature(s) to be available on the Document Manager.


To enable the expansion feature for DD Server Software, select

DD Function and click the   << Add   button.

Select the data folder (DD Folder) on the server.

- **[Options] - [DD Function] - [Print DD Cover]**
  Prints the DD Cover page selected in the document window

Image Converter

General Description

Once Panasonic-DMS has been installed, the Panasonic Document Manager (Image Converter) is automatically installed in the Printers folder. This driver is for rasterizing application files such as from Word or Excel, and for placing them in the Document Manager. To change the default properties, follow the instructions below:

Windows 98/Me

1. Click the **Start** button, select **Settings,** and then click **Printers**.

2. Right-click on **Panasonic Document Manager** and select **Properties** from the popup menu.
   The Properties dialog box appears.

   • **Paper/Layout tab**

   - **Paper Size**
     Sets the document paper size.

   - **Orientation**
     Sets the document orientation.

   - **Resolution**
     Sets the document resolution.

   • **Quality tab**

   - **Color**
     Sets the document color conversion to color or monochrome.

   - **Monochrome**
     Select Normal (Black and White) or Grayscale (Photo) when converting to monochrome. Also sets the brightness and contrast.

3. Click the [OK] button to save the settings and close the Properties dialog box.

Image Converter

Windows NT 4.0

1. Click the **Start** button, select **Settings,** and then click **Printers**.

2. Right-click on **Panasonic Document Manager** and select **Document Defaults** from the popup menu. The Document Properties dialog box appears.

• **Page Setup Tab**

 - **Paper Size**
   Sets the document paper size.

 - **Orientation**
   Sets the document orientation.

 - **Color Appearance**
   Sets the document to color or grayscale.

• **Advanced Tab**

 - **Paper Size**
   Sets the document paper size.

 - **Orientation**
   Sets the document orientation.

 - **Resolution**
   Sets the document resolution.

 - **Color Appearance**
   Sets the document to color or grayscale.

 - **Metafile Spooling**

 - **Halftone Color Adjustment**

3. Click the [OK] button to return to the Printers folder.

104

Windows 2000/XP

1. Click the **Start** button, select **Settings,** and then click **Printers**.

2. Right-click on **Panasonic Document Manager** and select **Printing Preferences** from the pop-up menu.
   The Printing Defaults dialog box appears.

    • **Layout tab**
       Sets the document orientation.

    • **Paper/Quality tab**
       Sets the document to color or grayscale.

    • **Advanced button**
   Sets the paper size, resolution, and spooling properties.

3. Click the [OK] button to return to the Printers folder.

Document Management System Section

105

Document Viewer

Main Window

The Document Viewer is an application for editing documents (image files) to be managed with the Document Manager (See page 88). In addition to usual image editing, the program provides various editing capabilities for documents with a wide selection of annotation functions.

Double-clicking on the document (thumbnail) in the Document Manager screen or selecting **Open** in the **Document** menu displays the main window of the Document Viewer. (See Note 1)

Main Window

1. **Title Bar**
   Displays the title of the screen and the name of the image file being displayed.

2. **Menu Bar**
   Displays the menus of the Document Viewer.

3. **Tool Bar**
   Displays tool buttons of the Document Viewer. Tool buttons correspond to functions of the menus in the menu bar.

4. **Page List**
   Displays the pages of the documents as thumbnails (reduced image).

5. **Size Bar**
   Adjusts the scaling of the display on the image window.

6. **Link Icon**
   Dragging and dropping a document on a link icon activates the application corresponding to each icon.

7. **Status Bar**
   Displays information such as image file name, image type, and size.

8. **Image Window**
   Displays the image and annotations of the pages being selected.

9. **Ruler**
   Displays the actual size of an image that is selected. The unit of measurement can be switched by **Detailed Settings ...**→**Ruler Unit** in the **View** menu.

Document Management
System Section

Document Viewer

Basic Operations

• **Selecting Page**
Selecting a page, by clicking it in the page list, displays an image of the selected page on the image window.

Dragging and dropping a page within the page list can change the order of the pages.

• **Image Editing**
The image displayed in the image window can be edited with the menu below:

- **Edit** menu
  Editing operations such as cutting, copying, pasting, and adding annotations.

- **Page - Adjust Page** menu
  Image correction and color balance adjustment of the whole page.

• **Selecting Area**
Dragging the mouse on the image window allows to select a specific area in an image. This function is used to save a specified area or to specify an area for annotation.

Annotation Function

Document Viewer provides functions to add various graphics and text to an image. The graphics and text added to an image are called <Annotation>.

The annotation function, unlike those in usual image editing applications, does not change the image itself but lays graphics and text on the image. Annotations and the original image are displayed as one image.

Annotations are managed separately from image data. Therefore, the Document Viewer can switch between displaying and hiding annotations.

If an image is edited with the Document Viewer, and is exported (sent) to another image editing application, it can be sent with the annotation to the image or not.

Annotation   Original image   Annotation added
                                            to the original image

Document Viewer

File Menu

• **Open**
Opens an image file saved in the computer.
Files of the following formats can be opened on the Document Viewer.

- **TIFF**
Tagged Image File Format (TIFF).

- **JPEG**
Joint Photographic Experts Group (JPEG) format.

- **BMP**
Windows standard bitmap format.

- **PNG**
Portable Network Graphics format.

- **DDM**
Document Manager file format.

• **Save** (See Note 1)
Saves a document being edited.

• **Save As** (See Note 1)
A document is saved as an ordinary image file under a specified name.

- **All page(s)**
Saves all pages in the document.

- **Select page**
Saves only the selected page.

- **Specified area**
Saves only the portion specified in the image window.

Document Viewer saves a file in the following formats:

- **TIFF**
Tagged Image File Format (TIFF).

- **Multi-page TIFF**
Multipages Tagged Image File Format (TIFF).

- **Internet Fax TIFF**
Tagged Image File Format (TIFF) with Internet Fax format.

- **JPEG**
Joint Photographic Experts Group (JPEG) format.

- **BMP**
Windows standard bitmap format.

- **PNG**
Portable Network Graphics format.

- **PDF**
Adobe Portable Document Format (PDF).

- **DDM**
Document Manager file format.

110

File Menu

• **Print**

Prints a document under the editing operation. For a document containing two or more pages, pages from-to can be specified for printing.

• **Print Setup**

Specifies the layout, printing size, and printing of annotations for a document to be printed.

1. **Vertical position and horizontal position**
   Adjusts the printing position on the sheet.

2. **Print Size**
   Select printing in original size or printing in accordance with the sheet size.

3. **N in 1 printing**
   Select for printing two or more reduced pages on one sheet.

NOTE

1. *When saving a document with annotations, save the document in the Document Manager file format (DDM). This format saves the annotations and image data separately (as objects) so that they can be edited later. Although saving a document in another format allows further editing, the annotations cannot be undone. They will be merged into the file.*

Document Viewer

File Menu

• **Launch To Another Application**
Opens the document selected in the document window with a specified application.

Selecting **External Application** (See Note 1) displays a dialog box for adding/changing/deleting applications.

Clicking the **Add** button displays the Add External Application dialog box.

1. **Name**
If an external application is specified, the name in this field appears on the link icon.

2. **Application Type**
Specify the application type.

3. **Program File**
Specify the execution file and the path of the application.

4. **MAPI Compliant**
Check here if the e-mail application is compatible with MAPI.

5. **Parameter**
If the e-mail application is incompatible with MAPI, adding a parameter here allows automatic activation of a transmission screen.

NOTE   1. See "Setting Plug-in" (page 92) to specify an external application.

File Menu

• **Trash Can**

 - **Open Trash Can**

  Opens the Trash Can and displays any page in it.

  Selecting page and clicking the [Undo] button restores page that has been discarded.

  Note: Once you exit the Document Viewer, the pages in the Trash Can are deleted.

 - **Empty Trash Can**

  Deletes the pages in the Trash Can. If a page is emptied from the Trash Can, it is permanently deleted. it is **Not** stored in the Recycle Bin.

Document Viewer

Edit Menu

• **Undo**
Undoes the last editing operation done.

• **Cut**
Deletes a selected annotation from a folder and copies it to the clipboard.

• **Copy**
Copies a selected annotation on the clipboard.

• **Paste**
Pastes an annotation from the clipboard into the selected page.

• **Clear**
Clears a selected annotation.

• **Select All**
Selects all annotations on the selected page.

View Menu

- **Drag Mode**
  Sets to the Drag Mode.

- **Clip Mode**
  Sets to the Clip Mode.

- **Edit Mode**
  Sets to the Edit Mode.

- **Zoom In**
  Zooms in on an image.

- **Zoom Out**
  Zooms out on an image.

- **Fits to Page Width**
 Fits the display to the page width.

- **Fits to Page Height**
  Fits the display to the page height.

- **Full Page**
  Fits the display to the full size page.

- **Original Size**
  Returns the display to the original size.

- **25% - 200%**
  Shows the display at 25% - 200%.

- **Detailed Settings**
  Sets detailed settings, such as thumbnail or page image settings.

115

Document Viewer

Page Menu

- **Next**
  Displays the next page.

- **Previous**
  Displays the previous page.

- **Top**
  Displays the top page.

- **Last**
  Displays the last page.

- **Select**
  Displays a specified page.

- **Auto Paging**
  Turns the pages automatically.
  - **Move Forward**
    Automatically steps through pages forwards.
  - **Move Backward**
    Automatically steps through pages backwards.
  - **Stop**
    Stops automatic page advance.
  - **Setup**
    Sets automatic page advance.

- **Move page**
  Moves pages to the desired position.
  - **Next page**
    Moves the current page to be after to the next page.
  - **Previous page**
    Moves the current page to be before to the previous page.
  - **Top page**
    Moves the current page to be the top page.
  - **Last page**
    Moves the current page to be the last page.
  - **Select page**
    Moves the current page to the page you specified.

- **Delete Page**
  Deletes the current page.

- **Copy Page**
  Copies the current page.

- **Add Page**
  Adds new pages from file to documents.
  Adds new pages from Twain scanner to documents.
  (The Twain Mode is not available in these models)

Page Menu

• **Insert Page**
  Inserts a page from file at the current position.
  Inserts a page from Twain scanner at the current position.
  (The Twain Mode is not available in these models)

• **Replace Page**
  Replaces the current page from file with a new page.
  Replaces the current page from Twain scanner with a new page.
  (The Twain Mode is not available in these models)

• **Rotate Page**
  - Rotate Right
    Rotates the page 90 degrees clockwise.
  - Rotate 180 Degrees
    Rotates the page 180 degrees
  - Rotate Left
    Rotates the page 90 degrees counterclockwise.

• **Adjust Page**
  - **Correct Skew**
    Adjusts orientation.
  - **Eliminate Noise**
    Eliminates the noise.
  - **Enhance Edge**
    Enhances the edge.
  - **Brightness/Contrast**
    Adjusts brightness or contrast.
  - **Hue/Chroma**
    Adjusts hue or chroma.
  - **Reverse Gradation**
    Reverse Gradation.
  - **Monochrome** (See Note 1)
    Converts to Monochrome.
  - **Grayscale** (See Note 2)
    Converts to Grayscale.
  - **RGB**
    Converts to RGB full color.

NOTE

1. *Grayscale and color information of a grayscale or RGB color image will be lost upon conversion into a monochrome image. The lost information is not restorable.*
2. *Color information of a RGB color image will be lost upon conversion into a grayscale image. The lost information is not restorable.*

Document Viewer

Page Menu

- **Copy Page to Clipboard**
  Copies the entire page selected onto the clipboard.

- **Copy Select Area**
  Copies select area to clipboard.

- **Select All Pages**
  Selects all pages.

## Annotation Menu

- **Show Annotation**
  The check box on/off setting specifies whether to display an annotation in the page list thumbnail.

- **Set Annotation**
  Protects the annotation from re-editing.

- **Annotation Order**
  - **Change Order To Top**
  - **Change Order To Last**
  - **Change Order To Previous**
  - **Change Order To Next**

- **Create Annotation**
  - **Text**
    Creates a text annotation and pastes it to a page.
  - **Line**
    Creates a line annotation and pastes it to a page.
  - **Rectangle**
    Creates a rectangular annotation and pastes it to a page.
  - **Ellipse**
    Creates an ellipse annotation and pastes it to a page.
  - **White block**
    Creates a white rectangular (solidly white-painted) annotation and pastes it to a page.
  - **Black block**
    Creates a black rectangular (solidly black-painted) annotation and pastes it to a page.
  - **Marker**
    Create a marker annotation and pastes it to a page.
  - **Label**
    Creates a label annotation and pastes it to a page.
 - **Stamp**
    Creates a stamp annotation and pastes it to a page.
  - **Date**
    Creates a date annotation and pastes it to a page.
  - **Page No.**
    Creates a page number annotation and pastes it to a page.

Document Viewer

Annotation Menu

• **Header**
Edits a header common to each page.

• **Footer**
Edits a footer common to each page.

• **Edit Text**
Sets a format of the text in a selected annotation.

• **Properties**
Displays annotation properties.

120

Annotation Menu

• **Text**

Creates a text annotation. Select text annotation in the annotation menu (or tool button), and drag the mouse in the image window to specify the display position.

A dialog box for text setup will appear.

Enter the text to display, and then specify text color and font. (See Note 1)

• **Line**

Creates a line annotation.

Select line annotation in the annotation menu (or tool button (See Note 2)), and drag the mouse in the image window to draw lines.

• **Rectangle**

Creates a rectangle annotation.

Select rectangle annotation in the annotation menu (or tool button (See Note 3)), and drag the mouse in the image window to draw a rectangle.

NOTE

1. To specify text font and colors, select the drawn text and select **Properties** in the **Annotation** menu. The Text Format Setup dialog box can be displayed also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn text.
2. To specify the thickness and color of a line, select a drawn line and then select **Properties** in the **Annotation** menu. Graphics Format Setup dialog box can be displayed also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn line.
3. To specify the thickness and colors of the rectangle, select the drawn rectangle and select **Properties** in the **Annotation** menu. The Graphic Format Setup dialog box can be displayed also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn figure.

Annotation Menu

• **Ellipse**
Creates an ellipse annotation.
Select ellipse annotation in the annotation menu (or tool button (See Note 1)), and drag the mouse in the image window to draw an ellipse.


NOTE

*1 To specify the thickness and colors of the ellipse, select the drawn ellipse and select **Properties** in the **Annotation** menu. The Graphic Format Setup dialog box can be displayed also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn figure.*

Annotation Menu

• **White Block**
Creates a white rectangle (solidly white-painted) annotation.
Select white annotation in the annotation menu (or tool button
(See Note 1)), and drag the mouse in the image window to
draw a white rectangle.

• **Black Block**
Creates a black rectangle (solidly black-painted) annotation.
Select black annotation in the annotation menu (or tool button
(See Note 2)), and drag the mouse in the image window to
draw a black rectangle.

NOTE

1. *To specify lines and colors of solid white, select the drawn solid white rectangle and select*
Properties *in the **Annotation** menu. The Graphic Format Setup dialog box can be displayed*
*also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn*
figure.
2. *To specify lines and colors of solid black, select the drawn solid black rectangle and select*
Properties *in **Annotation** menu. The Graphic Format Setup dialog box can be displayed also*
*by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn figure.*

Document Viewer

- **Marker**
  Creates a marker annotation.
  Select marker annotation in the annotation menu (or tool button (See Note 1)), and drag the mouse in the image window to draw a marker.

- **Label**
  Creates a label annotation.
  Select label annotation in the annotation menu (or tool buttons (See Note 2)), and drag the mouse in the image window to draw label displays Text Format Setup dialog box. Enter text to display and specify text color and font.

NOTE

1. *To specify the color of a marker, select the drawn marker and select* ***Properties*** *in the* ***Annotation*** *menu. The Graphic Format Setup dialog box can be displayed also by selecting* ***Properties*** *in the pop-up menu, that appears by right-clicking*
2. *To specify the color and font of a label, select the drawn label and select* ***Properties*** *in the* ***Annotation*** *menu. The Graphic Format Setup dialog box can be displayed also by selecting* ***Properties*** *in the pop-up menu, that appears by right-clicking on a drawn label.*

124

Annotation Menu

• **Stamp**
Creates a stamp annotation.
The stamp annotation pastes another image file like a stamp. Select stamp annotation in the annotation menu (or tool button) and click the OK button. Then drag the mouse in the image window to specify the area, displaying the stamp dialog box.

Click the Browse button to specify an image from a file.

Clicking the Add button allows to select image files to be used as a stamp.

Document Management System Section

Annotation Menu

• **Date**

Creates a date annotation.

Select date annotation in the annotation menu (or tool button), and drag the mouse in the image window to specify the area, displaying the Properties dialog box.

Specify the format, color, and font of the date to be displayed. (See Note 1)

1. **Font Name**
   Specify the font here.

2. **Style**
   Specify the font style.

3. **Size**
   Specify the font size.

4. **Text Color**
   Select the text color here.

5. **Date**
   Specify the date here. Selecting from the calendar or entering the date.

6. **Format**
   Specify the display format here.

7. **Text Align**
   Specify the text alignment.

1. *To specify the color or font of the date, select the drawn date and select **Properties** in the **Annotation** menu. The Text Format Setup dialog box can be displayed also by selecting **Properties** in the pop-up menu, that appears by right-clicking on a drawn figure.*

Annotation Menu

• **Page No.**

Creates a page number annotation.

Select page number annotation in the annotation menu (or tool button), and drag the mouse in the image window to specify the area. Double-click the Page No area to display the text the settings dialog box.

Specify format, color, and font of the page number to be displayed.

1. **Font Name**
   Specify the font here.

2. **Style**
   Specify the font style.

3. **Size**
   Specify the font size.

4. **Text Color**
   Select the text color here.

5. **Text Align**
   Specify the text alignment.

Opens the Graphics Format Setup Dialog box.
Click on the drawn figure and select Properties to change the thickness and colors of the lines.

1. **Line Width**
   Specify the thickness of the lines here.

2. **Line Style**
   Specify the types of lines here

3. **Line Color**
   Specify the color of the lines here.

4. **Fill Color**
   Select the color for solid painting here.

5. **Semitransparent**
   Set the image to transparent.

6. **Arrow Style**
   Select the Arrow style.

127

Document Viewer

Window Menu

- **Main Tool Bar**
  Show/hide main toolbar.

- **Page Tool Bar**
  Show/hide page toolbar.

- **Annotation Tool Bar**
  Show/hide page adjustment toolbar.

- **Image Tool Bar**
  Show/hide page adjustment toolbar.

- **Status Bar**
  Show/hide status bar.

- **Page List**
  Show/hide page list.

- **Ruler**
 Show/hide ruler.

- **Plugin**
  Show/hide plug-in.

Network Scanner

Network Scanner Settings

Startup Windows, and select **Panasonic** →**Panasonic Document Management System** →**Panasonic Communications Utility** in **Programs** from the Start menu.
The Panasonic Communications Utility is activated and the icon appears on the Task Bar.

• Scanner reception notification
  Right-click the Panasonic Communications Utility icon to the **Scanner reception notification** either **Pop up Display** or **Icon Display**.

<Pop up Display>
Displays the following message when the scanner image is received.

<Icon Display>
Changes the Status Monitor icon when the scanner image is received.

• Scanner Configuration
  Right-click on the icon and select **Scanner Configuration....**

129

Network Scanner

Network Scanner Settings

The Scanner Configuration Window appears as shown below.

• **Launch application**
Select the application among Document Manager / Windows Explorer / Other Application that will receive the scanner data.

• **Application**
Select the application program path to open the scanned image.

• **Save As File Type**
Select the file type to save the scanned image.

• **Save To**
Select the path to save the scanned image.

• **Scanner reception notice**
Select the view mode of the scanner reception notice.

<Address Information>
Select one of the following:

Auto Registration - The information below will be automatically registered in the Address Book of the device(s).

Manual registration at scanner - The Address Book of the device will be used to enter the computer's address manually.

• **Name**
Set the PC Name to be saved to the machine.

• **Key Name**
Set the Key Name to be saved to the machine.

• **Group ID**
Set the Group ID (1 -99).

• **Address Renewal Interval**
Set the period to update the address information to the machine.

Panasonic Communications Utility

Right-click the Panasonic Communications Utility icon on the Task Bar.
The Panasonic Communications Utility Window appears as shown below.

Set the activate program when double-clicking the Panasonic Communications Utility Icon.

• Scanner Configuration
  Open the Scanner Configuration Window.

• Fax Receive Log
  Open the Fax Receive Log Window.

• Exit the Panasonic Communications Utility.
  The Panasonic Communications Utility is terminated.

• Other

Click the   [Browse]   button to set the application program.

Panafax Desktop

General Description

Panafax Desktop is a PC Faxing application specifically designed to compliment the Panasonic line of multi-function products

Document(s) created on the PC can be easily faxed to a remote location directly, without having to print a hard copy first and then using the fax machine to send. This improves the copy quality received at the remote location, saving the cost and time of printing the hard copy locally before faxing it.

Compatible Models

  Network Connected Models

    Group 1
- DX-600 / 800
- DP-3510 / 4510 / 6010 with Fax and I-Fax Options
- DP-2310/3010 with Fax and I-Fax Options

    Group 2
- DX-1000/2000
- DP-1810F with I-Fax Option
- DP-2000/2500/3000 with Fax and I-Fax Options

  Local Connected Models
- UF-490/525 (Standalone System only)
- UF-590/790
- UF-890/990 (Tx only)
- DP-1810F

Restriction(s)

  Common
- The size of the data that can be transmitted is limited to the size that is within the memory of the device. The transmission is canceled when the device's memory overflows during the transfer of the fax data.
- The maximum number of multi-station transmissions is up to 999.

  Network Connected Models Only
- The total number of direct dialing stations of the device limits the total number of stations that a fax message can be transmitted to. The transmission is canceled when it exceeds that number during the data transfer to the device from the PC.

- For **Simple Send Only System with Group 2 Device(s)**, the fax data is transferred to the device continuously without confirmation of the job. The transmission is canceled when it exceeds the maximum number of stations, number of jobs or memory size of the device during data transfer to the device from the PC.

- For **Simple Send Only System or Send and Receive System with Group 1 Device(s)**, the fax data is transferred individually from the Panafax Desktop while obtaining the completion confirmation for each job, by means of the Job Completion Notice **(Send Only)** or Communication Journal **(Send and Receive)**.

    If you are running Anti-virus Software, it may interfere and/or cause the Panafax Desktop from sending a PC Fax Job to the Device properly. You may be required to disable the Anti-virus software when using the Panafax Desktop temporarily. Please consult your Network Administrator.

Connection Configurations (For the Network Connected Models)

For the Network Connected Models

There are two types of Panafax Desktop configurations, **Simple Send Only System** and **Send & Receive Network Shared System**.

|	Device Setting	PC Fax Setting
Simple Send Only System • Peer To Peer Connection • Email Server Not Required	• IP Address settings • Relay XMT Password setting • Relay XMT Report = Off setting*1	• Relay XMT Password setting
Send & Receive Network • Shared Network Connection • Email Server and RX Email Account Required	• IP Address settings • Relay XMT Password setting • Relay XMT Report = Always setting*2 • I-Fax setting • Fax Forward setting	• For the Server PC - Email Address settings - Relay XMT Password setting - Server setting - POP Receive setting - For the Client PC - Search Shared Server setting

Note:

*1: The result of the Simple Send Only System transmission with Group 2 Device models (refer to the list of compatible models in the previous section), the Send Log and TX Confirmation Notice confirms the transfer to the device only. The only way to confirm whether it reached the final destination is with a transaction journal of the device. (Pages sent column is 0)

*2: The result of the Simple Send Only System and Send and Receive System transmission with Group 1 Device models and all other compatible models, is reflected in the Send Log and TX Confirmation Notice. (Actual Pages Sent)

Simple Send Only System Connection Diagram

Panafax Desktop

Connection Configurations (For the Network Connected Models)

Send & Receive Shared Network System Connection Diagram

Transmit

Panafax Desktop Client PC — aaa
Panafax Desktop Client PC — bbb
Panafax Desktop Server PC — ccc

aaa bbb ccc

Send FAX

Transfer Fax Data **Transfer Fax Data**

LAN

Email Server

Receive

Panafax Desktop Client PC — ddd
Panafax Desktop Client PC — ddd
Panafax Desktop Server PC — ddd

ddd

Receive FAX

Fax Forward

View Shared Folder **POP Receive**

LAN

Email Server

Connection Configurations (For the Local Connected Models)

For the Local Connected Models
There are two types of Panafax Desktop configurations, the Standalone System and the Network Shared System.

	Device setting	PC Fax Setting
Standalone System - Standalone Connection	- PC-FAX RCV MODE = Print / Upload & Print / Upload	- None
Network Shared System - Shared Network Connection	- PC-FAX RCV MODE = Print / Upload & Print / Upload	For the Server PC - Server Setting For the Client PC - Search Shared Server setting

Standalone System

Send

Parallel cable

Transfer Fax Data

Receive

Parallel cable

Transfer Fax Data

135

Panafax Desktop

Connection Configurations (For the Local Connected Models)

Network Shared System

Transmit

Panafax Desktop Client PC | Panafax Desktop Client PC | Panafax Desktop Server PC

Parallel cable

Download Fax data

Send FAX

LAN

Transfer Fax Data

Receive

Panafax Desktop Client PC | Panafax Desktop Client PC | Panafax Desktop Server PC

Parallel cable

Upload Fax data

Receive FAX

LAN

View Shared Folder

Installation and Setup (For the Network Connected Models)

For the Network Connected Models

Panafax Desktop uses the fax modem in the Panasonic/Panafax models connected on your network (LAN) for fax communication.

Before using the **Panafax Desktop**, it is necessary to activate the Fax Modem and to setup certain parameters. Follow the steps below to setup the **Panafax Desktop**.

Installation

1	Confirm the following device settings.
	
	Send Only System settings:
	  Connection to the network
	  Set Internet parameters:
	    - IP Address
	    - Subnet Mask
	    - Default Gateway IP Address
	  Set Fax Parameters:
	    - Set the **Relay XMT Report** = off (Fax Parameter No. 143)
	
	Send & Receive System settings:
	  Connection to the network
	  Set Internet parameters:
	    - IP Address
	    - Subnet Mask
	    - Default Gateway IP Address
	    - Email Address
	    - Email Server Name/IP Address
	  Set Fax Parameters:
	    - Set the **Relay XMT Report** = Always (Fax Parameter No. 143)
	    - Set the **Fax Forward** to Receive Email Account (Fax Parameter No. 054)

2	Install the Document Management System. Refer to the Installation section of this Operating Instruction. **Note:** For the DP-1810F/DP-1810F (Network PC Fax) DP-2000/2310/2500/3000/3010/4510/6010, the Panafax Desktop does not install automatically with the **TYPICAL** installation. Select **CUSTOM** installation and check the Panafax Desktop to be installed. There is both a Parallel connection and Network connection Panafax Desktop for the DP-1810F. The model name of DP-1810F (Network PC Fax) is selected when using the **Network** version of Panafax Desktop and DP-1810F is selected when using the Local **(Parallel)** version of Panafax Desktop.

Document Management System Section

137

Panafax Desktop

Installation and Setup (For the Network Connected Models)

Basic Setup (Send Only System /Send & Receive System)

1

Double-click the icon on the Windows Desktop.

The **Panasonic Communications Utility** appears.

Click the OK button.

2

Device Search Ranges appears.

Click the Search Now button to start searching for the Network Connected Devices.

> **Note:** 1 *It searches for all the devices within the default Subnet. Refine the search range when there are many devices connected in the Subnet, or you want to connect to devices outside of the Subnet. To change the search range, click Add button and specify the range.*

Installation and Setup (For the Network Connected Models)

3

Starts searching for the PC Fax devices on the network.

4

The Network connected PC Fax device(s) are listed in the PC Fax Device Locator.

Select the desired Device and double-click or Click on **Properties** from the **Device** menu.

Document Management System Section

139

Installation and Setup (For the Network Connected Models)

5

The **PC Fax Properties** appears.
<**General**> Tab
Input the PC Fax Settings.
Send Only System:
  • Device's Email Address
    This Setting is unnecessary.
  • Device's Relay XMT Password
    The Relay XMT Password of the device.
  • Result Report Email Address
    This Setting is unnecessary. (See Note 1 and 3)

Send & Receive System:
  • Device's Email Address
    Set the Email Address of the device. (See Note 2)
  • Device's Relay XMT Password
    The Relay XMT Password of the device.
  • Result Report Email Address
    Set the POP Email Address for the reception. (See Note 3)
  Note: 1. If you have your own Email Address and your device is set up to Internet Fax , set your Email Address here. You can receive the Result Report from the device. In that case, set the Relay XMT Report = Always (Fax Parameter No. 143).
  2. Only the Email forwarded to the receiving account from this Email Address will be received. Input it precisely, otherwise it will not receive if the Email address doesn't match.
  3. When the Relay Domain is set in the User Parameters of the device, it is required to be the within the same domain (The right part of @) of the Email address for the Result Report Email Address. If it doesn't correspond, transmission from the Panafax Desktop is rejected.

<**Transmission/Reception**> Tab
  • Transmission Setting
   - Transmission Priority
     If there are multiple devices available, you can set the transmit priority of the device.
   - Dept counter mode On
     When the Department Code function is being used at the device, check the box and input the Identification Code
   - Start Status Monitor at sending
     Starts Status Monitor automatically at sending.
     The condition of the device can be monitored.
     The Device Group 2 doesn't have this function.
  • Reception Setting (Send & Receive System only)
   - Makes Reception Effective
     Check this box if you want to enable reception with this device.
  • Acquires Phone Book data from the device
   - Device's Password
     Device's Password to acquire the phone book data from the device, it is required to set the same password as the Password of the device.
 **Note:**
  1. The DX-600/800 uses the Remote Password. The DP-2310/3010/3510/4510/6010 uses the Key Operator Password.
  2. The Device Group 2 doesn't have this function.

Click on ☐ OK ☐ when you finish inputting the settings.

Installation and Setup (For the Network Connected Models)

6

Confirm that the device's Condition is in Standby (It takes a little while) using the PC Fax Device Locator.

Click ⨯ or select **Device** | **Exit** from the menu to close the PC Fax Device Locator.
For the **Send Only System**, the setup is completed.
For the **Send & Receive System**, continue to the Receive Setup on the next section.

Receive Setup (Send & Receive System only)

1

Click 🖥️ icon on the Windows Desktop.

The **Panafax Desktop** appears.
Select **Tools** | **PC Fax Device Locator** from the main menu.

2

The **PC Fax Device Locator** appears.
Select **Device** | **Detail Settings** from the menu.

Continued on the next page...

Installation and Setup (For the Network Connected Models)

3

The **Detail Settings** appears.

- Fax Log Data Folder
  - Location
    Specify the location to save the Fax log data. The default setting is generally acceptable.
- Shared Server Settings
  - The Shared and Account Name
    Set up when Panafax Desktop is used in shared mode.
- POP Server Settings for PC Fax Reception
  This is set up when Panafax Desktop uses the Receive function.
  POP Server settings and the receiving Email Account.
- PC Fax Transmit Setting
  - Max. number of Multi-Station TX
    Setup the maximum number of destinations to transmit to during one transmit request to a device.
    If the number of the destinations exceed this number, it will be divided into more than one transmission. When it is divided into several transmissions, and there are other devices available, it will transmit a request to multiple devices.

Click on [OK] when you finish inputting the settings.

Note:
1. *If your PC is running Windows NT/2000/XP and the client PC is running Windows 98/Me, it is necessary to use the Guest Account to use the Fax Server function. If a message comes up "Do you want to use the Guest Account?" click [Yes] to use the Guest Account.*
2. *When the Guest Account is made effective, a security problem may occur.*
   - *It will be possible to access common folders even if there is no account in Windows*
   - *The possibility that a computer virus could enter through this account.*
   Please set it after you confer with the Network Administrator.

4

Select the desired Device and double-click or Click on **Properties** from the **Device** menu.

142

Installation and Setup (For the Network Connected Models)

5

The **PC Fax Properties** appears.
Click **Transmission/Reception** tab and check the "Makes Reception Effective" box.

Click [OK] .

6

Confirm that the Reception status displays "**Yes**". It takes a moment.

Click [x] or select **Device | Exit** from the menu to close the PC Fax Device Locator.

The **Send & Receive System** setup is completed.

Document Management System Section

143

Installation and Setup (For the Network Connected Models)

Client Setup (Send & Receive System)

1

Click [icon] icon on the Windows Desktop.

The **Panasonic Communications Utility** appears.

Click the | OK | button.

2

Device Search Ranges appears.
Click on the [**Shared Network Connected Device(s)**] radio button.

Click the | Search Now | to start searching the shared Server.

> Note: *Searching sometimes may take a long time when there are many PCs connected to your network. In this case, we recommend to click [Add] button and specify the Domain or Workgroup, or specify the Computer Name directory to reduce the searching time.*

Look in

- Specified Domain or Workgroup
  Input device's Domain or Workgroup.
- Specified Computer Name
  Input the Server Computer Name.
- Shared Name
  Input the Server Shared Name if you changed from the default setting.
- Password
  Input the Server Password if you changed from the default setting.

Installation and Setup (For the Network Connected Models)

3

Start searching the Server for Network connected Devices.

4

The Network connected device via Server is listed in the PC Fax Device Locator.

Click ⌧ or select **Device | Exit** from the menu to close the PC Fax Device Locator.

The PC Fax (Shared Device) Properties appears. Click **Transmission/Reception** tab and checkout a box of "Makes Reception Effective".

Click [OK] .

Note: *The reception function is shown as "Yes" if the shared device's reception function is effective. If you do not wish to receive faxes, select the Device and double-click or Click Device | Properties from the menu.The PC Fax (Shared Device) Properties appears.Click Transmission/Reception tab and checkout the box for "Makes Reception Effective". Click*

[OK]

Panafax Desktop

Installation and Setup (For the Local Connected Models)

For the Local Connected Models

Panafax Desktop uses the fax modem in the Panasonic/Panafax models connected with your computer by parallel cable.

Before using the Panafax Desktop, it is necessary to activate the Fax Modem and to setup certain parameters. Follow the steps below to setup the Panafax Desktop.

Installation

1

Confirm the following settings of the device.

If you wish to receive change the following parameter as "Upload & Print" or "Upload".

PC-FAX RCV MODE = Print / Upload & Print / Upload (Fax parameter No. 063)

2

or

Install the Document Management System.Refer to the Installation section of these Operating Instructions.

Note: *1.* For the DP-1810F/DP-1810F (Network PC Fax) DP-2000/2310/2500/3000/3010/4510/6010, the Panafax Desktop does not install automatically with the **TYPICAL** installation. Select **CUSTOM** installation and check the Panafax Desktop to be installed.

There is both a Parallel connection and Network connection Panafax Desktop for the DP-1810F. The model name of DP-1810F (Network PC Fax) is selected when using the **Network** version of Panafax Desktop and DP-1810F is selected when using the Local **(Parallel)** version of Panafax Desktop.

2. For the Network Shared System, select

[Client] on the Select Setup Type screen during the installation.

Installation and Setup (For the Local Connected Models)

Setup for Standalone System

Special settings are unnecessary. It will be ready to send and receive fax massages if the device and PC are connected with the parallel cable and Panafax Desktop is started.

Note: Confirm that the device is not in the Energy Server Mode or Sleep Mode when you start Panafax Desktop.

Setup for Network Shared System

Server PC

Server Setup (Network Shared System)

1

Click [icon] icon on the Windows Desktop.

The **Panafax Desktop window** appears.

Select **Tools | PC Fax Device Locator** from the main menu.

2

The **PC Fax Device Locator** appears.

Select **Device | Detail Settings from** the menu.

3

The **Detail Settings window** appears.

Check the box for the "Shared Server Setting".

Click on ⌗ OK ⌗ when you finish the settings.

• Fax Log Data Folder
  Location
  Specify the location to save the Fax log data.
  The default setting is usually all right.
• Shared Folder Settings
  This is set up when Panafax Desktop is to be shared.

Panafax Desktop

Client PC

Client Setup (Network Shared System)

1

Double-click the [icon] icon on the Windows Desktop.

The **Panasonic Communications Utility** window appears.

Click the | OK | button.

2

Device Search Ranges appears.

Click the | Search Now | to start searching the shared Server.

> **Note:** 1. Note:Searching sometimes may take a long time when there are many PCs connected to your network. In this case, we recommend you to click | Add | button and specify the Domain or Workgroup, or specify the Computer Name directory to reduce the searching time.

• Look in
  - Specified Domain or Workgroup
    Input the device's Domain or Workgroup.
  - Specified Computer Name
    Input the Server Computer Name.
  - Shared Name
    Input the Server Shared Name if you changed from the default setting.
• Password
  Input the Server Password if it was changed from the default setting.

148

Installation and Setup (For the Local Connected Models)

3

Start searching the Server for Local connected Devices.

Device Search

Local connected Device via Server is searching now. Searching can be stopped by clicking the Cancel button.

Cancel

4

The Local connected devices via Server is listed in the PC Fax Device Locator.

Click ⌧ or select **Device | Exit** from the menu to close the **PC Fax Device Locator**.

PC Fax Device Locator
Device View Help

Device Name	Condition	Location	Model Name	Transmission Prio...	Reception
UF-590 - S04P...	Standby-Ready t...	\\S04PC084\Pa...	UF-590	1	Yes

1 PC Fax device(s)

5

PC Fax (Shared Device) Properties

General Transmission/Reception

Transmission Setting

Transmission Priority: 1

Reception Setting (Between Client and Shared PC)

☐ Makes Reception Effective

Check Interval: 30 Seconds

Delete   OK   Cancel

Note: *The reception function is shown as "Yes" if the shared device's reception function is effective. If you do not wish to receive faxes, select the Device and double-click or Click **Device | Properties** from the menu. The **PC Fax (Shared Device)** Properties appears. Click **Transmission/ Reception** tab and checkout a box of "Makes Reception Effective". Click* OK *.*

Document Management System Section

149

Panafax Desktop

Sending Document

Sending a Document via Windows Application

You can send a fax directly from any Windows Application by simply printing to the Panafax Desktop Driver. For example, compose a document from your word processor application. When you are finished and ready to fax it to a remote location, simply follow the procedure below.

1

From the current Application select **Print** from the **File** menu.

2

The **Print** dialog box appears.

Select **Panafax Desktop Driver** from the Printer Name menu.

Click the [OK] button to convert the document into a Fax image.

3

Enter the recipient's Fax No., Name and Company or select your Personal Phone Book.

Click the ▶ button to enter the recipient to the recipient list.
Enter/select another recipient if you desire.

Type the Subject in the Subject field and a brief message to be included in the Cover Sheet.

Click on the [Send] button when ready to send the fax.

> **Note:** *To input a pause, use the comma (,).*

4

Click on the [OK] button to start the transmission.

Sending Document

Sending a Document via the Panafax Desktop

You can send a fax directly from a file made in any Windows Application by simply attaching the file via the Panafax Desktop.
For example, compose a document from your word processor application. When you are finished and ready to fax it to a remote location, simply follow the procedure below.

1

Click ![icon] icon on the Windows Desktop.

The **Panafax Desktop** window appears.

Click on the ![Attach button] button to select a file for the transmission.

2

Select the file and click the [Open] button to convert the document into a Fax image.

3

From the Panafax Desktop window, enter the recipient's Fax No. , Name and Company or select from your Personal Phone Book.

Click the [▶] button to enter the recipient to the recipient list.
Enter/select another recipient if you desire.
Type the Subject in the Subject field and a brief message to be included in the Cover Sheet.

Click on the ![Send button] button when ready to send the fax.

Note: *To input a pause, use the comma (,).*

4

Click on the [OK] button to start the transmission.

Panafax Desktop

Sending Document

Sending a fax memo by Panafax Desktop

You can send a fax memo directly from the Panafax Desktop. This memo can be sent quickly and easily.

1

Click icon on the Windows Desktop.

The **Panafax Desktop** window appears.

2

From the Panafax Desktop window, enter the recipient's Fax No. , Name and Company or select from your Personal Phone Book.

Click the ▶ button to enter the recipient to the recipient list.

Enter/select another recipient if you desire.

Type the Subject in the Subject field and a brief message to be included in the Cover Sheet.

If you wish, click Cover Sheet to change the Cover Sheet Type.

    Note: *To input a pause, use the comma (,).*

3

Click on the OK button to start the transmission.

Receiving Document

Receive Setting

1

Confirm the Panasonic Communications Utility icon is in the taskbar tray.

2

Right-click the Panasonic Communications Utility Icon to show the menu and select the PC-Fax Reception Notification.

- Popup Display
- Icon Display
- No Notice

When a fax is received on the machine, it will proceed as follows:

1

A receiving notice appears on the connected PC.

Click the Receiving LOG button.

or

The Panasonic Communications Utility icon is changed.
Double click the icon.

2

The Receive Log appears.
Select a transaction from the log then click the

 button to view the received fax.

3

The received fax is displayed on the PC.

Panafax Desktop

Registering the Personal Phone Book

To register a recipient to the Personal Phone Book, follow the steps below:

1

Click on the [Phone Book] button to open the Phone Book dialog Box.

2

Click on the [New Entry] button.

3

<Contact> Tab
- Name:
  Enter the recipient's name.
- Fax No.:
  Enter the fax number.
- Call Type:
  Select how the call should be dialed.
  The code set up with Tools/Configuration/Dialing Settings is dialed at the head of the fax number.

  Note: *To input a pause, use the comma (,).*

4

<Data Fields> Tab
Enter the Company Name, Department, Job Title, Address, Direct Phone No. and the Extension Phone No. of the recipient to be used on the Cover Sheet.

5 Click the [OK] button to save the entry.

The maximum number entries is 2000.
To add another entry, repeat from the step 2.

154

Registering the Personal Phone Book

To register a group of recipients, follow the steps below:

1

Click the [Phone Book] button.

2

The **Phone Book** dialog box appears.

Click the [Edit Group] button.

3

The **Group Registration** dialog box appears.

Click the [New] button.

4

The **Add New Group Name** dialog box appears.

Enter the group name and click [OK] button.

Continued on the next page...

Registering the Personal Phone Book

To register a group of recipients, follow the steps below:

5

Select the desired recipients.

6

Click the ⟩⟩ button to add the recipient(s) to the Member List.

The maximum number of recipients is 999 for each group.

To add another group, repeat from step 3.

The maximum number of group's is 100.

If finished, click OK button to exit Group registration.

Registering the Personal Phone Book

To Import/Export CSV data From/To your Personal Phone Book
The telephone data of CSV format file can be imported into your Personal Phone Book and telephone data of your Personal Phone Book can be exported to a CSV file.
Note:
1. The "CSV file" means "Comma Separated Value" format file.
2. Though a pause usually is indicated as a comma (,) with Panafax Desktop, it is changed into "p" by the import and Export of the CSV file. Please input pause with "p" when you make a CSV file.

Import from the CSV file

1

On the Phone Book dialog box,Select **File | Import**... from the menu.

2

Select the file to be imported and click [Open].

3

Confirm the contents of the Data Field and Addressbook Field match.
Check off the item box if you do not want to import it.

Select the item and click [Change Mapping...] to change the field setting if the Data Field and Addressbook Field doesn't mach.

Click [OK] if you completed.

4

The telephone data of CSV file is imported into your Phone Book.

Registering the Personal Phone Book

Export to the CSV file

1

On the Phone Book dialog box,Select **File | Export...** from the menu.

2

Enter the file name and click [OK] to save the CSV file.

158

Cover Sheet

The **Cover Sheet** is attached to the first page of every fax and contains information such as the recipient's name, sender's name, date, title, etc.

Creating Cover Sheet

1

Click the [button]. button.

2

The Cover Sheet Editor window appears.
Edit the Cover Sheet.
Select **Save As** from the **File** menu.

3

The **Save as** dialog box appears.
Select the Folder you wish to save it to, or if you wish to save it into the New Folder,

click [New Folder] button,

enter the New Folder Name,

and then click [OK].

Continued on the next page...

Panafax Desktop

Cover Sheet

4

Enter the New Folder Name into the Cover Sheet File Name box.
Enter any comments into the Comment box if you want.

Click [Save] button to save the New Cover Sheet.

[Edit] menu

Page Size	:	Sets the size of the cover sheet.
Date Frame	:	Inserts a date field.
Text Frame	:	Inserts a text box.
Line/Box	:	Inserts a line or box.
Image Frame	:	Inserts an existing image file (bmp file).
Recipient Details	:	Inserts the information set in the [Contact] and [Data Fields] tabs on the Personal Address Book.
Sender Details	:	Inserts the information set in the [Sender Details] tab on the Tools menu.
Comments	:	Inserts a comment field for typing a brief message when sending a fax.
Subject	:	Inserts a subject field when sending a fax.

[View] menu

Show Grid	:	Displays the grid.
Preview	:	Displays the preview of the cover sheet.
Show Status Bar	:	Displays the status bar.
Zoom	:	Sets the ratio for the cover sheet editing screen.
Scale unit	:	Sets the scale unit of measure (cm/inch).

[Options] menu

|		
Font	:	Specifies the character font.
Line Style	:	Specifies the line style.
Text Alignment	:	Adjusts the text position.
Date Format	:	Sets the date format.

Main Window and Toolbar

Main Window

(1)	Fax No.	Enter the destination fax number.
(2)	Line Select	Check the line type to dial the preset code before the telephone number. See the Dialing Setting Tab of Configuration Menu.
(3)	Recipient	When this is entered, reflected on the cover sheet.
(4)	Company	When this is entered, reflected on the cover sheet.
(5)	recipient(s)	Indicates a number of entered station(s).
(6)	Destination(s)	Indicates entered destination station(s).
(7)	Subject	When this is entered, reflected on the cover sheet.
(8)	Memo field	When this is entered, reflected on the cover sheet.
(9)	Cover Sheet	Select various cover sheet or no cover sheet.
(10)	Attachment	Indicates a number of pages attached.
(11)	Resolution	Indicates a current sending resolution.

Document Management System Section

161

Panafax Desktop

Main Window and Toolbar

Toolbar

Icon	Description
Send	Used to start the transmission.
Preview	Used to view the cover sheet or transmission file.
Attach	Used to select the file to be sent.
Send/Receive Log	Used to show the Send/Receive Log Manager.
Phone Book	Used to open your personal Phone Book.
Cover Sheet Editor	Used to create or edit a Cover Sheet.
Help	Used to show the On-line help.

Configuration Menu

Configuration setting

Send Option Tab
Device Selection
  • Device Name:
    A device can be chosen here when more than one device is connected with network connected type devices.
  • Auto Selection:
    Effective device is selected automatically by the priority setting order.
  • Rotation:
    Effective device is selected automatically in rotation order. (load balancing)
  • Device Name:
    Only the designated device is selected.
  • Status/Location/Paper Size/Resolution:
    When the device is specified, the attributes of the device are indicated.
Page Setup
  • **Resolution:**
    Resolution to be used for the transmission.
    The selectable resolutions are dependent on the machine's capability connected to your PC.
  • **Setup Quality:**
    Set the quality to be used for the transmission.
  • **Use these as the default settings:**
    If checked, the settings selected are used each time a fax is sent.

Cover Sheet Tab
Setting the usage of the Cover Sheet.
  • Cover Sheet with specified fields
    The address information is inserted into the TO field of the Cover Sheet.
    The transfer time to the device sometimes becomes long because the image data is sent to the device multiple times in the case of multi-station transmission.
 • Cover Sheet with No specified fields (Generic)
    The address information is NOT inserted into the TO field of the Cover Sheet.
   The transfer to the device is done efficiently because the image data is sent to the device only once and only the address information is sent in the case of multi-station transmission.

Panafax Desktop

Configuration Menu

Dialing Settings Tab
Specify the local, long distance and Inter-office call access numbers. These access numbers are dialed before the phone numbers that are registered in the Personal Address Book depending on the Call Type settings.

Sender Details Tab
Used to identify yourself with various information on the Cover Sheet when sending a fax.

PIN Code Tab
Specify the PIN Code settings when required by your telephone system.
Depending on the country, the device may not support this function.

Various Settings Tab
• Device Phone Book
When this box is checked, the phone book data is acquired from the device at the time of startup, and it is added into the Personal Phone Book.
When this is used with the client & server, this function is effective only with the server PC
The setup of the password must be done for the device in the PC Fax Properties for the Network connected device.
• Notification Message
Various notices can be set up.

164

Send Log/Receive Log

Send/Receive Log

The transmission and the reception can be confirmed.

1

Click the [icon] button.

2

Send/Receive Log window appears.

Click Send Log and Receive Log to switch the Log window.

Status column

- Queuing: Send fax is queuing.
- Executing: Transferring the data to the device
- Completed: Transferring the data is completed

Result

- OK: The fax sending is completed from the device.
- Error Code: The fax sending is incomplete from the device.

Note: *1 For the Network Device Version of Simple Send Only System with the Device Group 2 (Please refer to the Compatible Models in General Description portion of this Operation Instruction), the Send Log shows whether only the transfer to the device succeeded (R-OK). "The fax sending is completed from the device" can be confirmed only by the Communication Journal of the device.*

2 For Network Device Version of the Simple Send Only System, the Receiving Log is not available.

3 For the Network Device Version of the Simple Send & Receive System and Local Device Version of Network Shared System, there is an Administrator Send Log that can check all the client(s) sending transactions. Select General User to see the Own Send Log and Administrator to see the Administrator Send Log. The Administrator Send Log can be setup with a password for security. To see the Administrator Send Log, Login with Administrator mode and check View | Displays All Users Send Logs. from the menu

Send Log/Receive Log

Save Log

The Send/Receive Log can be saved to a separate file.

At the default setting, when the log exceeds 999 transactions it is automatically deleted from the oldest transaction.

The log can be saved with the following steps.

Manual Save Log

1

On the Log window, select the transaction of the log that you wish to save and click [Save Log] icon.

2

Select the Folder that you want to save and click

OK .

You can make a new folder by clicking New Folder .

Note: The New Folder button is not available on Windows NT/98.

3

Select if you wish to Delete the Logs after saving.

4

The tiff file data (.tif) and the transmit file log information file (.xml) are saved as a set.

The log list files (sendlog.html/recvlog.html) are made automatically in the same folder. They can be viewed with a Web browser (IE 5.5 or higher).

Send Log/Receive Log

Automatic Save Log

1

On the Log window, select **Tools | Options** from the menu.

2

Option window appears.
Set the Save Log settings accordingly.

Network Device Locator

Select **Panasonic** →**Panasonic Document Management System** →**Network MFP Utilities** →**Network Deceive Locator** in **Programs** from the **Start** menu.
Upon activation of the Network Device Locator, attached printers will be automatically searched and displayed in the list.

Contents of List

Item	Status
Device Name	Name of the device.
Location	Location of the device.
IP Address	IP address of the connected device.
Make/Model	Make and model number of the device.
Condition	Display of Normal, Warning, Error, Powersaving, etc will be indicated after the status of the connected device is detected.

Right-click on your device to display the menu.

1. **Status Monitor**
   Activates the Status Monitor.

2. **Configuration Editor**
   Activates the Configuration Editor (See page 179).

3. **Address Book Editor**
   Activates the Address Book Editor (See page 179).

4. **Delete**
   Removes the device from the list.

5. **Rename**
   Changes the name of the device.

6. **Search**

   • **Device Search**
   Search the devices manually.

   • **Device Search Ranges**
   Set the conditions to search the devices (See page 169).

7. **Create Shortcut**
   Creates a Shortcut of the program for the selected device.

8. **Delete Shortcut**
   Deletes the selected Shortcut.

Network Device Locator

■ **Device Search Condition**

Select **Search** →**Device Search Ranges** from the **Device** Menu.

1. **Panasonic Printers**
   Select if searching for Panasonic printers only.

2. **All Printers**
   Select if searching for all printers.

3. **Add**
   Add a new search range of IP addresses.

   Click the ⬚ Add ⬚ button and enter the Start IP Address and End IP Address.

4. **Edit**
   Edit the selected IP address range.

5. **Delete**
   Delete the selected IP Address range.

6. **Detail**
   Enter the SNMP community name of the devices to be searched.

Network Status Monitor

Task Display

The Status Monitor is a Multi Functional Product (MFP) utility that monitors and displays the current status of connected devices.
Upon activation, the icon of the Status Monitor(up to 10 different printers) appear on the System Tray next to the system clock.

The Status Monitor indicates the device status by the icon lamp color as listed below.

Lamp	Status
Green	Device is operational under standby, printing, scanning, or copying mode.
Yellow	Device inspection is required, paper supply, etc.
Red	Need for toner replacement, open cover, paper jam, or device failure.
Gray	Device is in Energy Saver (sleep) Mode.

Taskbar Menu

Right-clicking the Status Monitor icon in the System Tray displays the following pop-up menu.

```
① Open Status Monitor
② Start the Configuration Editor
③ Start the Address Book Editor

④ Auto Start
⑤ Job Completion Notice            ►
⑥ Message Display
⑦ Pop up when error occurs

⑧ About
⑨ Exit
```

1. **Open Status Monitor**
   Displays details about the current status of the device.

2. **Start the Configuration Editor**
   Activates the Configuration Editor.

3. **Start the Address Book Editor**
   Activates the Address Book Editor.

4. **Auto Start**
   Sets the Status Monitor for the device to start automatically when the PC is rebooted.

5. **Job Completion Notice**
   Sets the Job Completion Notification mode.

6. **Message Display**
   Displays the contents (file name, etc.) of the Job Completion Notice when it is set to Icon (No Notice).

7. **Pop up when error occurs**
   Selects whether or not a pop-up error message box appears when an error occurs on the connected device.

8. **About**
   Displays the version information about the Status Monitor.

9. **Exit**
   Closes the Status Monitor.

Display Status Details

Right-clicking the Status Monitor icon in the System Tray and selecting **Open Status Monitor** in the pop-up menu displays the Status Monitor dialog box.

■ Status Tab

1. **Model**
   Displays the names and model number of the connected device.

2. **Status**
   Displays the current status of the device.

   If two or more items have been detected, clicking ⬅ / ➡ buttons allows viewing of other items.

3. **Control Panel**
   Displays information as it appears on the panel of the device.

   If two or more items have been detected, clicking ▼ / ▲ buttons allows viewing of other items.

4. **Message**
   Displays the current status of the device in details.

   If two or more items have been detected, clicking ⬅ / ➡ buttons allows viewing of other items.

5. **Status**
   Displays the communication status between the Status Monitor and the device.

Display Status Details

■ Configuration Tab

1. **Model**
   Displays the names and model number of the connected device.

2. **Configuration**
   Displays a list with the current device configuration (optional devices, etc.).

3. **Status**
   Displays the communication status between the Status Monitor and the device.

Display Status Details

■ **Paper Tab**

The Paper tab displays the type, size, and paper status of each paper tray. A comment by the user can be entered in the Paper Type field.

Not supported with pasted content

Display Status Details

■ **Network Tab**

1. **Model**
   Displays the names and model number of the connected device.

2. **Network Information**
   Displays a list of the current network status. (Number of packets for Sending/Receiving etc.)

Network Status Monitor

Display Status Details

■ **Job List Tab**

1. **Model**
   Displays the names and model number of the connected device.

2. **JOB List**
   Displays the current print jobs if the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed.

176

Job Completion Notice

Before using the Job Completion Notice, choose the Status Monitor as follows;

Pop up Display   : Notify with the Pop-up message.
Icon (Notice)   : Notify with the Icon appear on the desktop and change the Status Monitor icon.
Icon (No Notice) : Notify with the Status Monitor icon.
None   : Do not notify.

• Pop up Display
Displays the following message when the copy/print/fax job is completed.

177

Job Completion Notice

• Icon (Notice) and Icon (No Notice)

Displays the Notification Icon 🔲 on your desktop if **Icon (Notice)** is selected, and changes the Status Monitor icon.

Status Monitor icon

Select the Message Display to show the message.

Network Configuration Editor/Address Book Editor

General Description

These utilities allow you to edit the device's Configuration or Address Book through the TCP/IP LAN network using the FTP protocol. The desired device is first chosen from the device list of the Network Device Locator and then the Network Configuration Editor or Network Address Book Editor can be started.

Note: Both utilities are installed when the "Administrator" mode is selected during the Panasonic-DMS installation (See page 85).

Network Configuration Editor/Address Book Editor

Activation Procedure

1

Start the **Network Device Locator**. (See page 168)

2

The Network Device Locator appears.
From the Toolbar
Select the device from the list and click the

 or icon.

From the Tools menu
Select the device in the list and select
Configuration Editor or **Address Book Editor** from the **Tools** menu.

3

The Network Configuration Editor or Network Address Book Editor appears and retrieves the data from the device.

180

Network Configuration Editor/Address Book Editor

Create Shortcut Links

1

Start the **Network Device Locator**. (See page 168)

2

Click on the device and select **Create Shortcut →Configuration Editor** or **Address Book Editor** from the **Tools** menu.

3

The Shortcut Preparation window appears.

Select a Preparation Place and click the

| Create | button.

Note: *As the shortcut or menu icon includes the IP Address, the shortcut or menu icon has to be recreated each time if the IP Address of the device is obtained using a DHCP server on the network.*

4

The shortcut link is created at the selected place.

Main Window

Network Configuration	Address Book

Help Bar   Status Indicator   Help Bar   Status Indicator

Help Bar: Input or operation guide help is indicated.

Status Indicator: Communication status and the latest communication result are indicated.

Menus and Icons

Menu		Toolbar icon	Description
File	New		Creates a new blank file.
	Open		Opens an existing file.
	Close		Closes the active file.
	Save		Saves the settings to a file with its current name.
	Save As		Saves the settings to a file with a new name.
	File Information		Displays or changes the addresses of the device.
	Font		Selects the font which will print on reports.
	Print		Prints the active folder content.
	Delete		Deletes the file.
	Export file		Exports the active folder contents to a text file.
	Import		Imports the activate contents from a text file.
	Exit		Shuts down the application.
	Quit		Closes the active window without saving data.
Edit	Cut		Removes selected lines and places them on the clipboard.
	Copy		Copies selection lines to the clipboard.

Main Window

Menu		Toolbar icon	Description
	Paste		Pastes the contents of the clipboard at the insertion point of the line.
	Insert Line		Inserts a line at the insertion point of the line.
	Delete Line		Deletes a line at the deletion point of the line.
	Find Parameter		Searches for specified text in the active file.
	Set to default		Sets all settings of the active folder to its default settings.
View	List Mode		Displays list mode.
	Detail Mode		Displays detail mode.
	Sort		Selects the display sort mode.
	Toolbar		Shows or hides the Toolbar.
	Status Bar		Shows or hides the Status Bar.
	Font		Selects the display font.
Transfer	Retrieve		Retrieves the current settings from the device.
	Write		Writes the settings to the device. Selects either All data or Department Codes only.
	Display Log		Displays the transfer log.
Tools	Device Address List		Opens the Device Address List dialog.
	Device Group List		Opens the Device Group List dialog.
	Options	General		Opens the General setting dialog.
	Options	FTP Configuration		Opens the FTP Settings dialog.
Window	Tile Horizontal		Arranges the open windows in smaller sizes to all fit in the same window horizontally.
	Tile Vertical		Arranges the open windows in smaller sizes to all fit in the same window vertically.
	Cascade		Causes all windows to overlap so that each title bar is visible.
	Close All		Closes all open windows.
Help	Help Topics		Displays Help Topics.
	Supported Models		Displays a list of supported models.
	About		Displays information about Network Configuration Editor / Address Book Editor.

Basic Operation

Retrieve Data

1

Status Indication

When Network Configuration Editor or Network Address Book Editor is started from Network Device Locator or the pre-installed shortcut, it connects to the device, retrieves the data, and then displays it automatically.

A Process status is indicated in the bottom right side of the window.

> **Note:** *If the device password is changed (Key Operator Code) from the default value (0000), it is not possible to retrieve the data.*
> *In this case, enter the password in advance to the **Default Password** in the **Tools** →**Options** →**FTP Configuration...**.*

2

If you want to retrieve the latest data again from the device, click the icon, or select **Retrieve** from the **Transfer** menu.

> **Note:** *If the device is in an operating condition (copying, printing, etc...), it is not possible to retrieve the data (Retrieving error). Try again later after the device enters the standby condition.*

Network Configuration Editor/Address Book Editor

Basic Operation

Edit Data

1 Network Configuration Editor

Modify parameters using Network Configuration Editor.

When a function is chosen in the left pane of the window, the display of the right pane changes.

> **Note:** *Fields on the left show what items have been changed.*
> *   **:   An item which is different from default setting.*
> *   *#:   An item that has been changed.*

2 Network Address Book Editor

Modify, add or delete Address Book entries using Network Address Book Editor.

The type of Address Book to view or work with is chosen in the left pane of the window.

> **Note:** 1. *The Tandem Copy Address Book is available only when the optional Hard Disk Drive Unit (DA-HD30/HD60) is installed in the device.*
> 2. *The Fax Address Book is available only when the optional Fax Communication Board (DA--FG300/FG600) is installed in the device.*
> 3. *Before switching from the 200 to the 1,000 station Address Book style, please contact your authorized servicing dealer to initialize the existing Auto Dialers.*

185

Basic Operation

Write Data

1

If you want to write the edited data to the device, click the [icon] icon, or select **Write** from the **Transfer** menu.

2

Select [Yes] to start writing to the device.

3

Status Indication

Process status is indicated in the bottom right side of the window.

Note: *If the device is in an operating condition (copying, printing, etc...), it is not possible to write the data (Writing error). Try again later after the device enters the standby condition.*

186

Advanced Operation

Save retrieved data file

1

To save the retrieved setting data, click the

 icon, or select **Save As** from the **File** menu.

2

To Save File:

1. Select an existing file from the list or enter a new file name.

2. Click the   OK   button.
   The data is saved to a file.

Advanced Operation

Open saved file

1

To open a saved file, click the 📂 icon, or

select **Open** from the **File** menu.

> **Note:** *To start Network Configuration Editor or Network Address Book Editor, click [Configuration Editor] or [Address Book Editor] without selecting the device in the Network Device Locator. The editor will open without retrieving data from the device.*

2

To open a file:

1. Select a file from the list.

2. Click the [OK] button.

Advanced Operation

Create new file

1

To create a new file, for example to perform registration of an address book without connecting to the device, click the [ ] icon, or select **New** from the File menu.

> **Note:** *To start Network Editor, click [Configuration Editor] or [Address Book Editor] without selecting the device in the Network Device Locator. The editor will open without retrieving data from the device.*

2

The File Information window appears.

Click [▼] to select the model number.

Enter the device name, location and IP Address of the device (optional).

Enter the login password (Key Operator Code) of the device (optional).

Click the [OK] button.

3

The Save As window appears.

Enter a new file name.

Click the [OK] button.

4

The editing window appears.

Edit items as necessary.

Network Configuration Editor/Address Book Editor

Advanced Operation

Registering the Device Address List

1

To open the Device Address List, click the

 icon.

2

Click the:

[Acquire] button:
To acquire the network address list of the Network Device Locator.

[Add...] button:
To enter a new address setting into the dialog boxes.

[Edit] button:
To select the address that you want to edit and edit the current settings.

[Delete] button:
To select the address that you want to delete.

[Connect] button:
To connect the address that you want to retrieve and display the data.

[OK] button:
To make the changes effective, and to close the window.

[Cancel] button:
To discard all changes and close the window.

Network Configuration Editor/Address Book Editor

Advanced Operation

Registering the Group List

1

To open the Device Group List, click the icon.

2

The Group Name List, lists the registered groups.

Click the:

| New | button:

To create a new group.

Enter a name and click | OK |.

| Update | button:

To change the name of the selected group.

Enter a new name and click | OK |.

| Delete | button:

To delete the selected group.

The Device Address List, lists the addresses of registered devices.

Click the:

| Acquire | button:

To acquire your network address list that the Network Device Locator detected.

The Group Member section lists registered addresses for the selected group.

Use the | >> | << | buttons to add or delete the selected address from the group members.

191

Network Configuration Editor/Address Book Editor

Advanced Operation

Using the Device Address List and Device Group List

The destination can be specified in the Address Book or Group List.

1

The confirmation window appears before retrieving or writing data.

Click the [Change Dest.] button.

2

Destination section:
This shows the addresses currently chosen.

3

Manual Inpu tab:

Enter the address and click the [>>] button to add the address to the destination.

4

Device Address List tab:

The addresses which the Address List and Group List registered are shown.

Select an address, and add or delete it by clicking the [>>] or [<<] button.

> **Note:** *Multiple destinations can be entered only when Dept Code only is selected from the Transfer | Write menu. [Options...] is indicated when there is a writing option.*

5

Click [OK] to return to the Confirmation window.

192

Advanced Operation

Using Timer Communication

1

The confirmation window appears before retrieving or writing data.

Click the [Change Dest.] button.

2

Timer section:

Click **Enable** and select the time that you want to start communication.

Click [OK] to create the job to standby in the spooler until the start time.

Cancel Timer Communication

1

Click **Spooler** in the taskbar to open the Spooler.

2

If you need to cancel the job, select the job and choose **Delete** from the **Spooler** menu.

193

Network Configuration Editor/Address Book Editor

Advanced Operation

Editing the Address Book Editor – Copy and Paste Address Book data

1

Open the source data file and target data file.
(See page 179)
Select **Window →Tile Horizontal**.

2

Select the range that you want to copy.

Click on the first number that you want to copy and then click on the last number that you want to copy while pressing **[Shift]** key.

or

Click on the first number that you want to copy and drag the mouse until you reach the last number you want to copy.

3

Right-click on the selection and select **Copy**, or select **Copy** from the Edit menu.

4

Click on the first number where you want to paste the data.

Network Configuration Editor/Address Book Editor

Advanced Operation

5

Right-click and select **Paste**, or select **Paste** from the Edit menu.

6

The data is pasted at the designated point.

**Note:** *The data which exceeds the maximum number of allowable addresses will be lost.*

Document Management System Section

195

Network Configuration Editor/Address Book Editor

Advanced Operation

Editing Address Book Editor – Import Address Book data from other application

Address Book data created using other applications, such as Microsoft Excel, can be imported.

1

Copy the Address Book data from the other application.

The data format must be Address (IP Address/Fax number/Email Address), Destination Name and Key Name.

2

Click on the number where you want to paste the data.

Right-click and select **Paste**, or select **Paste** from the Edit menu.

3

Data is pasted at the designated point.

> **Note:** *The data which exceeds the maximum number of allowable addresses will be lost.*

196

Troubleshooting

Printing Operation Fails

If the printing operation fails, check the following items first:

• The connection cable (Parallel/USB cable or Ethernet LAN cable) is properly connected.
• Power of the device is turned ON.
• Paper is loaded properly in the device.
• An error message is not displayed on the device. (See Note 1)

The above points can be verified by printing a test page. Refer to the following for procedures on test page printing:

Troubleshooting

Document is Not Printed Correctly

| Problem	Possible Solution(s)
Printing position is wrong or print is missing at the edge.	Paper size or printing orientation is different between the application settings and the printer driver settings. Specify the settings again. The specified paper has not been loaded on the device. Specify the settings again or load the appropriate paper. The document margin is not sufficient. On the machine, a margin of approx. 0.1 inch (2.5 mm) or more is required at the sheet edges. (Recommended printing margin) Adjust the margin correctly.
Characters and symbols not used in documents are printed.	Verify that your machine has been selected as the printer driver.
Printing operation takes excessive time.	The wait time for printing operations depends on the spool settings. Select **Spool print jobs so program finishes printing faster** in spool settings. • Reference : Windows 98/Me [Details Tab] (See page 44) Windows NT 4.0 [Scheduling Tab] (See page 53) Windows 2000/XP [Advanced Tab] (See page 65)
Although print data is transferred to the digital copier, it does not print.	• Make sure the printer is on line. • Make sure the machine is not in the **Shutdown Mode**. Press **ENERGY SAVER** key to return to standby mode. See the Operating Instructions for Copier & Network Scanner for details.

## Error Messages Displayed on the Computer

Problem	Possible Solution(s)
Error in writing to LPT1/USB. Unable to write to the Specified device.	Verify that the device is connected to the computer correctly. Verify that the power of the device is turned on. Verify that the paper is properly loaded.

Error in writing to LPT1/USB. Printer timeout error occurred.	Verify that the power of the device is turned on.
	Excessive data volume or number of pages may overflow the device's memory, disabling data reception.
	Increase the timeout setting value in properties (for transmission retry).
	  • Reference :
	    Windows 98/Me [Details Tab] (See page 44)
	    Windows NT 4.0 [Ports Tab] (See page 52)
	    Windows 2000/XP [Ports Tab] (See page 64)

Printing is disabled due to an error in the current printer settings.	Differences in settings such as paper size or printing orientation exist between the application and the printer driver. Specify the correct settings.

Appendix

Printing/Scanning Area

When printing to the device, there is a 0.1 inch (2.5 mm) non-printable area on all 4 sides.

Top

0.1 (2.5)

0.1 (2.5)   0.1 (2.5)

0.1 (2.5)

Bottom   Unit: inches (mm)

200

memo

Appendix

For Service, Call: _____